

DV32 For Units Equipped with Robertshaw 7000 MVRLC Gas Valve

Item/Model Number	Part Number
1. REAR LOG	52336
2. FRONT LOG	52337
3. LEFT LOG	52339
4. RIGHT LOG	52338
5. LOG SET COMPLETE	52335
6a. MAIN BURNER NAT. W/CERAMIC	52528
6b. MAIN BURNER LP W/CERAMIC	53625
7. FRONT BURNER	52345
8. MAIN ORIFICE NAT. #47	50995
9. MAIN ORIFICE LP #57	53552
10. FRONT ORIFICE NAT. #56	52625
11. FRONT ORIFICE LP #71	51702
12. GAS VALVE NAT. (R.S.)	51833
13. GAS VALVE LP (R.S.)	51835

DV32 For Units Equipped with Robertshaw 7000 MVRLC Gas Valve

Item/Model Number	Part Number
14. PILOT NAT. (R.S.)	51826
15. PILOT LP (R.S.)	52741
16. PIEZO IGNITOR	50932
17. IGNITOR ELECTRODE	50931
18. THERMOPILE	51827 or 7533113
19. SENSOR FLAME	51834
20. CERAMIC TILE SET	52347
21. BURNER TRAY COMPLETE NAT.	52287-3
22. BURNER TRAY COMPLETE LP	52287-4
23. BRASS TRIM	52428-PB
24. GLASS FRAME	52554
25. GLASS W/GASKET	52522
26. GLASS GASKET	N/A
27. WALL SWITCH	51842
28. WALL SWITCH PLATE	51843
29. WALL SWITCH WIRE (10 FT)	N/A
30. EMBER MATERIAL	51915
31. TOP LOUVRE	52357-1
32. LOUVRE ACCESS DOOR	52361-1
33. BOTTOM ACCESS DOOR HINGES (EA.)	52356
34. FIRESTOP	52523
35. PILOT TUBING	53309