

<u>Description</u>	<u>Part No.</u>
1. Log Rear.....	08423
2. Log Front.....	08425
3. Log Left.....	06498
4. Log Right.....	17429
5. Log Set Complete.....	08420
6. Burner Main Nat w/ceramic.....	52583
7. Burner Main LP w/ceramic.....	52613
8. Burner Front Nat.....	52575
9. Burner Front LP.....	52576
10. Orifice Main Nat. #45.....	52585
11. Orifice Main LP #56.....	50999
12. Orifice Front Nat. #55.....	52584
13. Orifice Front LP #71.....	51702
14. Valve Gas Nat.....	51833
15. Valve Gas LP.....	51835
16. Pilot Nat.....	51826
17. Pilot LP.....	52741
18. Ignitor Piezo.....	50932
19. Electrode Ignitor.....	50931
20. Thermopile.....	51827

<u>Description</u>	<u>Part No.</u>
21. Sensor Flame.....	51834
22. Ceramic Tile Set.....	50317
23. Burner Tray Complete Nat.....	08370-4
24. Burner Tray Complete LP.....	08370-5
25. Glass Frame - Outer.....	50146-I
26. Glass Frame.....	50145
27. Glass w/Gasket.....	50130
28. Glass Gasket.....	52949-6
29. Wall Switch.....	51842
30. Wall Switch Complete.....	50451
31. Wall Switch Wire (10 ft).....	53010-I
32. Ember Material.....	51915
33. LouvreTop.....	52892
34. Louvre Access Door.....	52891
35. Access Door Hinges (Ea.).....	52356
36. Firestop.....	52523
37. TubingPilot.....	53309
38. Instruction Manual DV34.....	52774
39. Warranty Sheet.....	51811

PartsPlus.com