

DV40

Item/Model Number	Part Number
1a. COMPLETE LOG SET	52943
1b. LOG FRONT	52982
2. LOG REAR	52983
3. LOG RIGHT (#1)	52984
4. LOG RIGHT CENTRE (#2)	52985
5. LOG LEFT CENTRE (#3)	52986
6. LOG LEFT (#4)	52987
7. MAIN BURNER NGW/CERAMICS	53002
8. MAIN BURNER LP W/CERAMIC	53003
9. ORIFICE MAIN #36 NG	52981
10. ORIFICE MAIN #55 LP	50998
11. ORIFICE FRONT #53 NG	51930
12. ORIFICE FRONT #69 LP	52980
13. FRONT BURNER NG/LP	52974
14. GAS VALVE NG.	52677 or 7529141
15. GAS VALVE LP	52444
16. PILOT NG	52445

DV40

Item/Model Number	Part Number
17. PILOT LP	52446
18. PIEZO IGNITOR	50932
19. CABLE ELECTRODE	51850
20. ELECTRODE IGNITOR	52465
21. THERMOPILE	51827 or 7533113
22. THERMOCOUPLE	51848
23. FRAME WINDOW	52746
24. GLASS W/GASKET	53004
25. GLASS GASKET	N/A
26. COVER, FRAME ASSEMBLY	50146-2
27. WALL SWITCH KIT (WHITE)	50451
28. EMBER MATERIAL	51915
29. TOP LOUVRE	52357-2
30. LOUVRE ACCESS DOOR	52361-2
31/33. REFRACTORY LINING SET	53057-1
31. REFRACTORY LINING LEFT SIDE	N/A
32. REFRACTORY LINING CENTRE	N/A
33. REFRACTORY LINING RIGHT SIDE	53021
34. FAN SPEED CONTROL (NOT SHOWN)	51738
35. FAN CONTROL KNOB (NOT SHOWN)	51882
36. TEMPERATURE SENSOR (FAN) (N/S)	51704
37. FAN (NOT SHOWN)	52612