

# DVRT41

Ref.	Description	DVRT41
1.	Log Set DVRT41 (Complete)	10006185
1a.	Log Rear (G7)	10006798
1b.	Log Front Right (G6)	10006797
1c.	Log Front Left (G10)	10006801
1d.	Log Front Center (G9)	10006800
1e.	Log Crossover Left Top (G8)	10006799
2.	Volcanic Rock	20000376
3.	Lava Rock - Burner	57897
3a.	Platinum Embers	78037
4.	Bracket Rear Log Assembly Black	10006780
5.	Grate Assembly	10006332
6a.	Burner Housing Assembly - NG	10006177
6b.	Burner Housing Assembly - LP	10006395
7.	Ceramic Tile (Single)	57803
8.	Manifold Assembly	10003207
9.	Refractory CR Kit DVRT41	10006718
9a.	Refractory Lining Base Right	10006713
9b.	Refractory Lining Base Left	10006714
9c.	Refractory Lining Right	10006715
9d.	Refractory Lining Left	10006716
9e.	Refractory Lining Rear	10006717
10.	Glass with Gasket Assembly DVRT41	10006719
11.	Gasket Glass	10000992
12.	Window Assembly DVRT41	10006720
13.	Clamp Frame Window	54174
14.	Louvre Assembly Top	10000039
15.	Louvre Assembly Bottom	10000040
16.	Bottom Louvre Hinge	52356
17.	Deflector Top	54364
18.	Orifice Rear Burner - Nat. (not shown)	Refer to Rating Plate for Orifice Specifications
19.	Orifice Rear Burner - LP (not shown)	Refer to Rating Plate for Orifice Specifications
20.	Orifice Front Burner - Nat. (not shown)	Refer to Rating Plate for Orifice Specifications
21.	Orifice Front Burner - LP (not shown)	Refer to Rating Plate for Orifice Specifications
22.	Switch Rocker	53606
23.	Switch ON/OFF	51842
24a.	Valve - Honeywell VS8421 - Nat.	10001782
24b.	Valve - Honeywell VS8421 - LP	10001759
25a.	Valve - SIT 820 - Nat.	52677
25b.	Valve - SIT 820 - LP	52678
26a.	Pilot Assembly - SIT Top Conv. - Nat. (3 way)	10002264
26b.	Pilot Assembly - SIT Top Conv. - LP (3 way)	10002265
27.	Electrode Ignitor w/Cable	10001297
28.	Nut Electrode	57886
29.	Pilot Tube 1/8" x 24" Long w/Fittings (SIT Pilot)	10001296
30.	Thermocouple - RN/RP	53373
31a.	Valve - SIT 822 - EN	57884
31b.	Valve - SIT 822 - EP	57883
32.	Thermopile - RN/RP	51827
33.	Hood Pilot 3 Way	10002385
34a.	Pilot Assembly SIT Top Conv. - EN	10002387
34b.	Pilot Assembly SIT Top Conv. - EP	10002388
35a.	Pilot Orifice #65 - Nat.	10002268
35b.	Pilot Orifice #35 - LP	10002269

36a.	Ignitor Piezo Honeywell	20000062
36b.	Ignitor Piezo w/Nut SIT	50903
37.	Air Shutter - LP	10000879
38.	Air Shutter - Nat.	10001117
39.	Fan w/Bracket (FK24)	54103
40.	Electrical Cord (6ft.)	51865
41.	Fan Temperature Sensor	51704
42.	Speed Control	51738
43.	Speed Control Knob	51882
44.	Remote ON/OFF Switch Kit (not shown)	53875
45.	Transformer EN & EP	7522409
46.	Ignitor Module Honeywell EN & EP	20000005
47.	Sensing Electrode w/Cable EN & EP (not shown)	57885
48.	Wire Harness, Honeywell EN & EP (not shown)	57899
49.	Firestop	52523
50.	Zero Clearance Sleeve	54623
51.	7" Starter Pipe	56054
52.	4" Starter Pipe	56053
53.	Plate Cover Air Inlet w/7" Collar Assy	10002766
54.	Gasket Plate Air Inlet	10002449
55.	Plate Cover Flue Products	10002298
56.	Gasket Plate Cover Flue Products	10002233
57.	Plate Flue Pipe Assy.	10004933
58.	Gasket Plate Cover Flue Pipe	10002237
59.	Antennae HW 395783-1 RFN/RFP Valve	20003561
60a.	RF Valve 8310E - Nat.	20003719
60b.	RF Valve 8310E - LP	20003720
61.	Thermopile - RF Valve	20002400
62a.	Pilot Orifice - Nat. RF	20000908
62b.	Pilot Orifice - LP RF	20000907
63a.	Pilot Assembly - Nat. (3 way) RF	20002266
63b.	Pilot Assembly - LP (3 way) RF	20002268
64.	Transmitter	20002047
65.	Cord Set RF Valve	20002541
66.	Pilot Tube 1/8" x 24" Long w/Fittings (PSE Pilot)	10003279
67.	Refractory Bay Window	10000506
68a.	Regulator Head - Nat.	10001006
68b.	Regulator Head - LP	10001007
69a.	Label Console	10006496
69b.	Label Console RF Valve	10006824
70.	Gasket Base Burner	10006154
71.	Plate Relief w/Gasket Assembly	10002429
72a.	Console w/Stud Assembly Black	10006807
72b.	Console RF Valve	10006795
73.	Shield Pilot	10006263
74.	Plate Relief w/Gasket Assembly Burner Tray	10004192

#### Fuel Conversion Kits

##### Natural Gas to LP

DVRT41RN/EN Kit #10006826  
DVRT41RFN Kit #10006827

##### LP to Natural Gas

DVRT41RP/EP Kit #10006825  
DVRT41RFP Kit #10006828