

Enviro EX32 Insert PARTS LIST

Reference Number	Part Description	Part Number
1	Door Release Tool	50-2510
2	Flue Adapter Tool	50-3505
3	EX32 Flue Adaptor	50-3521
4	EX32 Flue Adaptor Gasket	50-3522
5	Door Spring Latches (set of 2)	50-2507
6	EX32 Log Tray Assembly	50-3523
7	EX32 Burner Pan	50-3524
8	EX32 Light Tray Cover	50-3525
9	EX32/EX35 Light Tray Assembly	50-3512
-	Halogen Socket w/ Wires	50-2028
10	EX32 Door Complete	50-3526
11	Glass C/W Gasket (26.25" x 16")	50-2506
-	Dual Bulb Door Gasket (10ft)	50-634
12	Safety Screen	50-3072
13	Log Set (9 Pcs.)	50-3502
14	Brick Liner Set	50-2509
-	Ledgstone Liner Set	50-2774
-	Porcelain Liner Set	50-2427
15	EX32/EX35 Pilot Shield	50-3514
16	EX32 Stainless Steel Baffle	50-3527
17	Top Light Assembly	50-3516
18	Fan Only	50-2493
19	Proflame 2 IFC (0.584.325)	50-3312
-	Proflame 2 IFC Wire Harnes (0.584.924)	50-3030
20	Battery Holder 4 x AA	50-3027
21	Proflame 2 Transmitter (0.584.045)	50-3028
22	885 Proflame IPI Valve NG	50-2682
23	PSE IPI Pilot Assembly	50-3026
24	2A Glass Fuse	50-2075
25	Replacement Halogen Bulb	50-3291
26	Ceramic Wire Nut (set of 2)	50-3517
27	Proflame 2 Transmitter (0.584.040)	50-3265
-	Power Cord (115V)	EC-042
-	Strain Relief	EC-044
-	EX32 Conversion Kit NG to LP	50-3503
-	EX32 Conversion Kit LP to NG	50-3546
-	Ceramic Wool Embers Only	50-893
-	12 oz. Can of Metallic Black Touch Up Paint	PAINT-12-MB