

Efel Harmony 31 Oil Parts List

1.

1	35262	Loading Lid Cast Black H8 H34
1	9304	Loading Lid Green H8 H34
1	39320	Loading Lid Satin Black H8 H34
2	40065	Protection Plate Load Lid H8
3	RO138	Rope Seal Set H8 Oil Gas 24 25
4	37696	Top Plate Cast Black H8 Oil
4	37698	Top Plate satin Black H8 Oil
4	39301	Top Plate Green Enamel H8 Oil
5	38487	Rear LH Heat Shield H8 Oil
6	40064	Protection Plate Top Plate H8
7	37708	Halfmoon Blank Plate H8 Cast
8	FF5005	M5 x 16 Pozi Pan BZP
9	34452	Flue Spigot 4in Cast H5 H8 H10
10	FF5028	M5 Stud 50mm
11	FF5001	M5 Washers Plain BZP
12	FF5000	M5 Nut Full BZP
13	26231	Washer Concave for Enamel Flue
14	FF5013	M5 x 20 Pozi CSK BZP
15	34452	Flue Spigot 4in Cast H5 H8 H10
15	38205	Flue Spigot 4in Satin Harmony
15	40333	Flue Spigot 4inch Green H5 Oil
16	MS1013	Choke Flue H1 H2 H5
17	33585	Top Flue Adaptor H5 H8 H10 Oil
18	RO192	Flat S/A Rope Seal 500mm
19	FF7701	Self Tapping Screw No12x3/8in
20	34285	Gasket Ceramic Top Flue
21	37711	Side Panel L/R H33 Cast Black
21	37713	Side Panel L/R H33 Satin Black
21	39326	Side Panel L/R H33 Green
22	38051	Combustion Box Stanford 80 Oil
23	32875	Identification Plate H5 S50
24	14618	Screw Self Tap Hex Head
25	38488	Rear RH Heat Shield H8 Oil
26	32828	Handle - Furnace Door H5 H13
26	MS91077	Handle Set Nickel H5 only
26	MS91094	Handle Set Black Chrome H5
27	37702	Front Panel H8 Cast Blk
27	39300	Front Panel H8 Green

Woodman's Parts Plus
www.woodmanspartsplus.com

27	37704	Front Panel H8 Satin Black
28	14618	Screw Self Tap Hex Head
29	RO1121	Rope 8mm dia Glass Fibre
30	3940	Wing Nut M5 Steel BZP
31	37711	Side Panel L/R H33 Cast Black
31	37713	Side Panel L/R H33 Satin Black
31	39326	Side Panel L/R H33 Green

2.

26	32828	Handle - Furnace Door H5 H13
26	MS91077	Handle Set Nickel H5 only
26	MS91094	Handle Set Black Chrome H5
27	37702	Front Panel H8 Cast Blk
27	39300	Front Panel H8 Green
27	37704	Front Panel H8 Satin Black
28	14618	Screw Self Tap Hex Head
29	RO1121	Rope 8mm dia Glass Fibre
30	3940	Wing Nut M5 Steel BZP
31	37711	Side Panel L/R H33 Cast Black
31	37713	Side Panel L/R H33 Satin Black
31	39326	Side Panel L/R H33 Green
32	RO138	Rope Seal Set H8 Oil Gas 24 25
33	37973	Glass H8 Oil
34	37726	Door Furnace Cast Blk H8 H33
34	39302	Door Furnace Green H8 H33
34	37728	Door Furnace Satin Blk H8 H33
35	FF5042	M5 x 10 Pozi Pan S/Steel
36	MS078	Glass Seal Set H1 2 8 10 14
37	MS078	Glass Seal Set H1 2 8 10 14
37	13479	Glass Retaining Clip Harmony
38	11390	Burner Gasket 6 and 8 Burner
39	26428	Catalyser 8 inch Mk2 Single
40	FF5000	M5 Nut Full BZP
41	FF5005	M5 x 16 Pozi Pan BZP
42	23908	Catalyser Support 8 inch MK2
43	46263	Oil Burner 8 inch H31
44	38048	Rear LH Support Pillar H8 Oil
45	38050	Rear RH Support Pillar H8 Oil
49	16149	Decoking Assembly
50	38500C	Igniter Kit Short Oil Stove
51	MS078	Glass Seal Set H1 2 8 10 14
52	FF5000	M5 Nut Full BZP

53	38547	Latching Pin Lower Door H5 S50
54	FF5006	M5 x 20 Pozi Pan BZP
55	FF5024	Nut M5 Square
56	39778	Latch Lower Door H5 S50
57	FF5012	M5 x 16 Pozi CSK S/S
58	26231	Washer Concave for Enamel Flue
59	FF5000	M5 Nut Full BZP
60	12430	Nut Brass Domed 8mm Furnace
61	17496	Washer Brass Front Door Hinge
62	18906	Hinge Pin - H23 H33 H8 H10
63	43802	Door Lower H33 Cast Blk
63	43805	Door Lower H33 Green Enamel
63	43804	Door Lower H33/H31 Satin Blk
64	FF5001	M5 Washers Plain BZP
65	FF5005	M5 x 16 Pozi Pan BZP
66	32827	Hinge Lower Door H5 H8
67	32723	Circlip Ash Pan Door
73	30033	Badge Nestor Martin with bolt

3.

75	41109	Knob Oil Control MK3 H5 H8 H10
78	38489	Support Control Knob H8
79	14618	Screw Self Tap Hex Head
80	40033	Rod Knob to Oil Valve H31
83	DR017	Control Cable Long 460mm
84	33781	Baffle H8 Oil
86	14618	Screw Self Tap Hex Head
87	33783	Stop Gap H5 Multifuel
88	17369	Breather Tube Oil Valve H5 S50
89	112	Olive
91	38955	Protection Plate Burner Oil
92	26687	Tube Draught Test H5 S50 Oil
93	32803	Log Guard H5 Oil/Gas [P]
94	35268	Base Plate H8 Gas
95	FF3004	M3 x 10 Pozi Pan BZP
96	FF3000	M3 Nut Full BZP
97	DR017	Control Cable Long 460mm
98	2805	Draught Stabilizer 5in al Efel
99	MS2110	Split Cotter Pin 1 1/4"x3/32
100	DR019	Brass Channel Draught Control
101	FF3019	M3 x 8 mm Bolt Hex Head
102	FF3000	M3 Nut Full BZP

103	29551	Oil Valve Toby 5.5-17.5cc
103	MS10061	O Ring Toby DVR Metering Stem
103	MS10062	Filter Gasket Toby Oil Valve
104	32782	Support Oil Valve H5 H8 H10
105	1504	Nut Oil Connection
106	FF6000	M6 Nut Full BZP
107	FF6001	M6 Washers Plain BZP
108	FF6005	M6 x 16 Pozi Pan BZP
109	MS999	No Part Number Listed
109	1504	Nut Oil Connection
109	112	Olive
110	14618	Screw Self Tap Hex Head
112	37932	Transformer Oil Stoves
113	20194	Switch Less Button Ignition
113	20195	Button Cap - Push Ignition
115	31756	Power Cord Oil Stove UK Spec
116	38093	Floor Protection Plate H8 Oil
117	FF5020	M5 x 20 Hex Head Set Screw BZP
118	38099	Plinth H8 S80 H31
118	38101	Plinth H8,S80 H31 Satin Black
118	38252	Plinth H8 H31 Green Enamel
119	RO1261	Rope 12mm dia Glass Fibre per
120	35273	Foot Cast Black H8 H10 H33
120	39299	Foot Satin Black H8 H10 H33
120	39298	Foot Green Enamel H8 H33
121	FF8024	M8 x 60 HT Hex Bolts BZP
122	FF8001	M8 Washers Plain BZP
123	FF8000	M8 Nut Full BZP
124	27078	Grub Screw for Foot Adjustment
125	27078	Grub Screw for Foot Adjustment
126	20019	Tool Riddling and Lifting
127	MS38548	Glove Red Leather Pair
128	27437	Touch Up Green Enamel
128	FB161061	Touch Up Black Enamel
129	40785	Paint Spray Cast Black Stove
132	CE101	Coal Set Loose for Oil
132	CE102	Ceramic Coal Base Oil
133	DR010	Sub Frame Draught Stabilizer
134	DR021	Actuator Shaft End Cap
135	DR011	Cam Draught Stabilizer
136	DR014	Magnet Anisotropic Large
137	DR015	Magnet Anisotropic Small

138	DR012	Spindle Cable Actuator
139	FF3019	M3 x 8 mm Bolt Hex Head
140	DR013	Spring Return Mechanism
141	FF3019	M3 x 8 mm Bolt Hex Head
142	FF3002	M3 Washer Spring
143	FF3000	M3 Nut Full BZP
144	DR018	Slide Bar Draught Control
145	FF3000	M3 Nut Full BZP
4.		
91	38955	Protection Plate Burner Oil
92	26687	Tube Draught Test H5 S50 Oil
93	32803	Log Guard H5 Oil/Gas [P]
94	35268	Base Plate H8 Gas
95	FF3004	M3 x 10 Pozi Pan BZP
96	FF3000	M3 Nut Full BZP
97	DR017	Control Cable Long 460mm
98	2805	Draught Stabilizer 5in al Efel
99	MS2110	Split Cotter Pin 1 1/4"x3/32
100	DR019	Brass Channel Draught Control
101	FF3019	M3 x 8 mm Bolt Hex Head
102	FF3000	M3 Nut Full BZP
103	29551	Oil Valve Toby 5.5-17.5cc
103	MS10061	O Ring Toby DVR Metering Stem
103	MS10062	Filter Gasket Toby Oil Valve
104	32782	Support Oil Valve H5 H8 H10
105	1504	Nut Oil Connection
106	FF6000	M6 Nut Full BZP
107	FF6001	M6 Washers Plain BZP
108	FF6005	M6 x 16 Pozi Pan BZP
109	MS999	No Part Number Listed
109	1504	Nut Oil Connection
109	112	Olive
110	14618	Screw Self Tap Hex Head
112	37932	Transformer Oil Stoves
113	20194	Switch Less Button Ignition
113	20195	Button Cap - Push Ignition
115	31756	Power Cord Oil Stove UK Spec
116	38093	Floor Protection Plate H8 Oil
117	FF5020	M5 x 20 Hex Head Set Screw BZP
118	38099	Plinth H8 S80 H31
118	38101	Plinth H8,S80 H31 Satin Black

Woodman's Parts Plus
www.woodmanspartsplus.com

118	38252	Plinth H8 H31 Green Enamel
119	RO1261	Rope 12mm dia Glass Fibre per
120	35273	Foot Cast Black H8 H10 H33
120	39299	Foot Satin Black H8 H10 H33
120	39298	Foot Green Enamel H8 H33
121	FF8024	M8 x 60 HT Hex Bolts BZP
122	FF8001	M8 Washers Plain BZP
123	FF8000	M8 Nut Full BZP
124	27078	Grub Screw for Foot Adjustment
125	27078	Grub Screw for Foot Adjustment
126	20019	Tool Riddling and Lifting
127	MS38548	Glove Red Leather Pair
128	27437	Touch Up Green Enamel
128	FB161061	Touch Up Black Enamel
129	40785	Paint Spray Cast Black Stove
132	CE101	Coal Set Loose for Oil
132	CE102	Ceramic Coal Base Oil