

Empire CIVF-25C-1 Part List

PARTS LIST

| Index No. | Part Number | Description |
|---|-------------|---|
| 1 | R3436 | REMOTE/OFF/ON SWITCH |
| 2 | CI326 | SWITCH BOX |
| 3 | CI199 | WIRE CHANNEL ASSEMBLY |
| 4 | CI335 | REAR COVER |
| 5 | R3643 | REAR LOG |
| 6 | R3644 | TOP LOG |
| 7 | R3642 | FRONT LOG |
| 8 | CI023 | BURNER BRACKET - RIGHT |
| 9 | CI258 | AIR SHUTTER BODY |
| 10 | R3612 | BURNER |
| 11 | R3623 | PILOT ASSEMBLY-LPG W/THERMOPILE AND THERMO-COUPLE |
| 11 | R3624 | PILOT ASSEMBLY-NAT W/THERMOPILE AND THERMO-COUPLE |
| 12 | CI180 | PILOT TUBING |
| 13 | CI166 | BURNER BRACKET - LEFT |
| 14 | CI338 | LOG SUPPORT |
| 15 | CI351 | LOG SUPPORT BAFFLE |
| 16 | CI207 | INNER BOTTOM |
| 17 | CI027 | INNER BOTTOM FACE ASSEMBLY |
| 18 | *CI009 | LEG PAD - B (2 REQUIRED) |
| 18 | *CI008 | LEG PAD - N (2 REQUIRED) |
| 20 | P8654 | ORIFICE-LPG |
| 20 | P8640 | ORIFICE-NAT |
| 21 | CI176 | MANIFOLD ASSEMBLY |
| 22 | R3625 | GAS VALVE - LPG |
| 22 | R3628 | GAS VALVE - NAT |
| 23 | R3623 | MAGNET ASSEMBLY (2 REQUIRED) |
| 24 | CI068 | VALVE COVER ASSEMBLY |
| 25 | R2708 | PIEZO IGNITOR |
| 26 | CI231 | GLASS FRAME ASSEMBLY |
| 27 | R3628 | GLASS-SIDE (2 REQUIRED) |
| 28 | R3627 | GLASS FRONT |
| 29 | CI030 | INNER BODY |
| 30 | CI192 | REFLECTOR |
| 31 | CI189 | INNER TOP FACE |
| 32 | CI187 | INNER TOP |
| 33 | CI208 | CATALYST HOLDER |
| 34 | R3629 | CATALYST ELEMENT (2 REQUIRED) |
| 35 | CI211 | OUTLET DUCT ASSEMBLY |
| 36 | CI217 | OUTLET DUCT SHIELD |
| Not Shown | R2789 | ELECTRODE WIRE |
| Not Shown | R3765 | WIRE ASSEMBLY |
| Not Shown | * CI007 | RETAINING TAB (4 REQUIRED) |
| Not Shown | * R3747 | LEVELING BOLT (4 REQUIRED) |
| Not Shown | *CI006 | WINDOW RETAINING TAB |
| * PART IS INCLUDED IN THE HARDWARE PACKAGE AND IS USED IN THE ASSEMBLY OF THE STOVE CASTING | | |