

- | | | |
|--------------------------------|--------------------------------------|---------------------------------------|
| 1. BASE | 39. LARGE GLASS CLIP | |
| 2. LEG | 40. TOP COVER PLATE TO DOOR FRAME | |
| 3. HOB | 41. BOTTOM COVER PLATE TO DOOR FRAME | |
| 4. GUIDE PLATE TO FRONT | 42. CONTROL KNOB | |
| 5. TOP COVER PLATE | 43. SHAFT | |
| 6. FLUE SPIGOT | 44. SPACER | |
| 7. FRONT FRAME | 45. TOP AIR DUCT PLATE | |
| 8. FIRE DOOR | 46. SECONDARY AIR BAFFLE | |
| 9. ASHPIT DOOR | 47. SPRING | |
| 10. OUTSIDE BACK AIR DUCT | 48. CLAMP PLATE TO GASKET | |
| 11. DOOR GRILL PANEL | 49. TOOL HOLDER | |
| 12. LEFT SIDE PANEL | 50. AIR WASH GASKET | |
| 13. RIGHT SIDE PANEL | 51. FIRE DOOR GLASS | |
| 14. AIR WASH CHAMBER | 52. FIRE DOOR GASKET | |
| 15. AIR WASH SHUTTER | 53. ASHPIT DOOR GASKET | |
| 16. INSIDE TOP FRAME | 54. HOB GASKET | |
| 17. INSIDE TOP COVER PLATE | 55. AIR WASH CHAMBER GASKET | |
| 18. FLUE OUTLET | 56. | |
| 19. ASH LIP | 57. INSIDE TOP COVER GASKET | |
| 20. INSIDE BACK PLATE | 58. BRICK CLIPS | |
| 21. | 59. GRILL PLATE TO FIRE BOX | |
| 22. FRONT FIRE FENCE | 60. BYPASS SHUTTER | |
| 23. BACK PLATE | 61. ASHPIT SHUTTER | |
| 24. BACK BRICK | 62. GUIDE RAIL FOR SHUTTER | |
| 25. TOP SIDE BRICK | 63. BASE BRICK | |
| 26. BOTTOM SIDE BRICK (RIGHT) | 64. PUSH ROD | |
| 27. FRONT BRICK | 65. HANDLE TO SHUTTER | |
| 28. DOOR HANDLE SHAFT | 66. PIN TO DAMPER | |
| 29. | 67. REAR BLANKING PLATE GASKET | |
| 30. FIRE DOOR LATCH | 68. BLANKING PLATE FOR BACK PLATE | |
| 31. SPACER TO FIRE DOOR LATCH | 69. HEAT SHIELD TIE BOLTS | |
| 32. BOTTOM SIDE BRICK (LEFT) | 70. BACK HEAT SHIELD SPACERS (2") | |
| 33. SPACER | 71. BACK HEAT SHIELD SPACERS (1") | |
| 34. LONG DOOR HANDLE | 72. REAR HEAT SHIELD BLANKING PLATE | |
| 35. SHORT DOOR HANDLE (ASHPIT) | 73. PIPE SHIELD (OPTIONAL) | |
| 36. ASHPAN | 74. DOUBLE TOP FLUE SPIGOT | HEAT SHIELD
ASSEMBLY
(OPTIONAL) |
| 37. MULTI-PURPOSE TOOL | 75. INSIDE REAR HEAT SHIELD | |
| 38. SMALL GLASS CLIPS | 76. OUTER REAR HEAT SHIELD | |