

FA20

Item/Model Number	Part Number
1. LOG - FRONT	50427
2. LOG - REAR	50423
3. LOG - LEFT TOP	06498
4. LOG - RIGHT TOP	17429
5. LOG - SET COMPLETE	50420
6a. MAIN BURNER C/W CERAMIC NAT.	52837
6b. MAIN BURNER C/W CERAMIC LP	52838

FA20

Item/Model Number	Part Number
7. PILOT ASSEY (SEE MATRIX ATTACHED)	
8a. ORIFICE - MAIN BURNER NAT. #47	50995
8b. ORIFICE - MAIN BURNER LP #59	51701
9a. ORIFICE - FRONT BURNER NAT #59	51919
9b. ORIFICE FRONT BURNER LP #73	51703
10a. FRONT BURNER NAT.	11378
10b. FRONT BURNER LP	11442
11a. IGNITOR ELECTRODE (SIT) <i>(NOT SHOWN)</i>	52465
11b. IGNITOR ELECTRODE C/W WIRE (ROBERTSHAW)	50931
12. IGNITOR CABLE (SIT)	51850
13a. PILOT TUBE C/W FITTINGS ROBERTSHAW	53309
13b. PILOT TUBE C/W FITTINGS SIT	53211
14. GLASS C/W GASKET	52873
15. GLASS GASKET	52949
16. WINDOW FRAME ASSEMBLY	52700
17. INTERRUPTER BLOCK	51852
18. FAN SPEED CONTROL	51738
19. FAN SPEED CONTROL KNOB	51882
20. SWITCH BOX COVER	50205
21. FAN	53312
22. FAN TEMPERATURE SENSOR	51704
23. ELECTRICAL CORD	51865
24. EMBER BURNING MATERIAL	51915
25. ACCESS DOOR HINGE	51762
26. SPILL SWITCH WIRING HARNESS	52549
27. SPILL SWITCH SENSOR	51866
28a. IGNITOR PIEZO SIT <i>(NOT SHOWN)</i>	52464
28b. IGNITOR PIEZO ROBERTSHAW <i>(NOT SHOWN)</i>	50931
29a. VALVE COVER C/W PIEZO IGNITOR	51851
29b. IGNITOR PIEZO	52464
29c. IGNITOR CABLE	53194

FA20

Model	Thermocouple	Thermopile	Valve	Pilot Assembly
FA20TN	52684	N/A	52685	52683
FA20TP	52684	N/A	52686	52682
FA20MN	51830	N/A	51832	51826
FA20MP	51830	N/A	52885	52741
FA20RN	51830	51827	52779	51826
FA20RP	51830	51827	51835	52741
FA20RNB	51830	51827	52779	51826
FA20RPB	51830	51827	51835	52741

WoodmansPartsPlus.com