

FC300F Exploded Parts List - REVISED JUNE 20'

<u>Item #</u>	<u>Description</u>	<u>QUANTITY</u>
1	Cabinet Top - FC3TOP	1
2	Right Side Cabinet - FC3RSF	1
3	Left Side Cabinet - FC3LSF	1
4	Firebox Assembly - FC3SHELL	1
5	Rear Baffle - FC3RB	1
6	8" Duct Ring Collar - FC8C	1
7	Side Firebrick - FCJ5041- 13 1/2" X 4 1/2" X 1 1/4"	2
8	Side Firebrick - HTFB - 9" X 4 1/2" X 1 1/4"	2
9	Wood Grate - FCWG	2
10	Knob - FCKIMOB	1
11	Spin Draft - FCSD	2
12	Fuel Door Assembly - FCFD	1
13	Fuel Door Gasket 5/8" - FCGSKT58	45"
14	Fuel Door Handle - FCFDH	1
15	Fuel Door Latch - FCDL	1
16	Hinge Pin - FCHP	2
17	Ash Drawer Assembly - FC3AD	1
18	Smoke Curtain - FCSC	1
19	Smoke Curtain Clip - FCSCHDW	2
20	1/4" X 20 X 3/4" Bolt - <i>included with FCSCHDW</i>	2
21	Circulation Blower - FC300BM	1
22	Cord for Blower - FC3CORD	1
23	Junction Box - FC670	1
24	Fan Thermo-Disc - FC3DISC90/110	1
25	Conduit Assembly - FCCON	1

OPTIONAL Filter Box FCFB300 NOTSHOWN