

Item No.	Description	Part Number
1	Collar, Flue (Cabinet)	511070
2	Gasket, Flue Collar (Cabinet).	511076
3	Strip, Insulation Retainer (Short).	511518
4	Back, Cabinet AssemblyX511102
5	Insulation, Cabinet Back	511087
6	Side Cabinet, Left Side.X511100
6A	Panel, Cabinet (Lower Front)	511084
7	Shield, Floor.	511389
8	Top, Cabinet Assembly.X511099
8A	Insulation, Cabinet Top (Not Shown).	511088
9	Strip, Insulation Retainer (Long)	511519
10	Insulation, Cabinet (Right and Left Side).	511085
11	Side, Cabinet Right SideX511101
12	Gasket, Washer (Brick Clamp)	510452
13	Leveler, Adjustable Leg.	511513
14	Pin, Hinge (Cast Doors).	510197
15	Gasket, Ash Door	511051
16	Latch, Ash Door.	510774
17	Door, Ash.	510170
18	Grate Support AssemblyX510867
19	Bottom, Firebox (False).	510145
20	Shield, Handle	510654
21	Firebox AssemblyX511095
22	Plate, Adjustment (Secondary).	510164
23	Gasket, Flue Pipe Assembly	510335
24	Pipe, Flue Assembly.X511387
25	Retainer, Rear Brick Assembly.	.X511104
26	Plate, Brick Retainer.	511289
27	Firebrick.	510161
28	Retainer Shaker (Back)	510255
29	Support, Rear Brick.X511103
30	Handle, Cast Doors	510168
31	Ash Pan AssemblyX510171
32	Screw, Eyelet.	510578
33	Handle, Pull (Wood).	510577
34	Poker.	510198
34A	Rake Assembly.X511384

Item No.	Description	Part Number
35	Shaker Grate, Right Side. . .	510251
36	Retainer, Shaker (Front) . . .	510254
37	Shaker Grate, Right Side . . .	510252
38	Grate.	510250
39	Gear, Shaker	510253
40	Cotter Key	121435
41	Handle, Shaker	510256
42	Liner, Firebox (Right Side). .	510155
43	Spacer, Brick.	511106
44	Bracket "Z" Right SideX511290
44A	Bracket "Z" Left Side (Not Shown).X511291
45	Clamp, Smoke Baffle.	510583
46	Smoke Baffle	510258
47	Lock Nut $\frac{1}{4}$ - 20.	510257
48	Washer, Spacer	51C
49	Latch Assembly (Load Door) .	.X510
50	Door, Load	510448
51	Tinnerman Clip	121269
52	Box, Draft (Feed Door)	510451
53	Gasket, Load Door.	511050
54	Thermostat, (Bi-metal)	511520
55	Door, Draft.X510815
56	Rod, Thermostat.	511027
57	Disc, Friction (Outside)	510185
58	Pin, Hinge (Draft Door).	510165
59	Housing, Thermostat Assembly	.X511177
60	Disc Friction (Inside)	510222
61	Spring, Thermostat	510182
62	Washer	120479
63	Cotter Key	121267
64	Cover, Assembly (Thermostat)	.X510890
65	Plate, Thermostat.	510450
66	Knob, Thermostat	510180
67	Nameplate (COALMASTER)	510262
68	Cover, Junction Box.	511523
69	Switch, Operation Control. . . .	511521
70	Junction Box (Operating Control)	511522
71	Grate Assembly (Items 28,35, 36, 37, 38, and 39).	53

BLOWER ASSEMBLY

Item No.	Description	Part Number
1	Cover, Air Filter Access	511082
2	Retainer, Air Filter	511094
3	Filter	511116
4	Blower Wrap AssemblyX511098
5	Blower Assembly (Housing Motor and Wheel)	511114
6	Connector, Blower AssemblyX511097
7	Bracket, Blower Mounting	511081
8	Plate, Side (Blower Wrap)	511080
9	Cover, Junction Box.	511198

Item No.	Description	Part Number
10	Fastener, Housing.	230256
11	Relay.	230135
12	Thermostat (Bi-metal) (Honeywell)	510470
13	Arkless Connector.	230223
14	Bushing, Strain Relief	230604
15	Wire Nut	230531
16	Transformer.	230574
17	Junction Box Assembly.X511197
18	Thermostat (24 Volts).	160651
19	Wire, Thermostat	230165