

Item No.	Description	Part Number
1	Cabinet, Left Side.	511014
2	Top, Cabinet.	511015
3	Back, Cabinet	510446
4	Front, Cabinet.	510442
5	Left Panel.	510445
6	Right Panel	510444
7	Top Panel	510447
7A	Gasket, Top Panel (Not Shown)	510456
8	Firebox Assembly.	X510433
9	Gasket, Flue Collar	510335
10	Flue Collar	510783
11	Plate, Secondary Air.	510164
12	Rear Support Assembly	X510273
13	Retainer, Firebrick	510572
14	Firebrick	510161
15	Retainer, Firebrick (Side).	510575
17	Clamp, Smoke Baffle	510583
18	Smoke Baffle.	510258
19	Grate Support	X510867
20	Gear, Shaker.	510253
21	Retainer, Shaker Front.	510254
22	Shaker Grate, Right	510252
23	Grate	510250
24	Retainer, Shaker (Back)	510255
25	Shaker Grate, Left.	510251
26	False Bottom.	510145
27	Pin, Hinge (Cast Door).	510197
28	Ash Door.	510170
29	Handle. Door.	510623

Item No.	Description	Part Number
30	Gasket, Ash Door.	510625
31	Latch, Door	510774
32	Handle, Shaker Grate.	510256
33	Poker	510198
34	Ash Pan with HandleX510861
35	Heat Liner, Right Side.	510854
36	Box, Draft Feed Door.	510451
37	Load Door	510448
38	Gasket, Load Door (Not Shown)	510626
39	Adjustment Nut.	121382
40	Thermostat Assembly (Bimetal)	.X510530
41	Pin, Hinge (Draft Door)	510165
42	Friction Disc, Outside.	510185
43	Housing, Thermostat	510187
44	Friction Disc, Inside	510222
45	Spring, Thermostat.	510182
46	Washer.	120479
47	Cotter Key.	121267
48	Cover Assembly, Thermostat.X510890
49	Plate, Thermostat	510650
50	Knob, Thermostat.	510180
51	Name Plate (Coalmaster)	510535
52	Rod, Thermostat	510471
53	Draft Door Assembly	510418
54	Tinnerman Clip.	121269
55	Lock Nut, 1/4-20.	510225
56	Grate Assembly CompleteX510283
	(Includes items 20, 21, 22, 23 24 and 25)	