

FAHRENHEIT ENDURANCE PARTS LIST

Item	Part Number	Description	Item	Part Number	Description
1	150057-60255SE	Air Pump	18	CS1-1550	Top Panel Assembly
2	CS1-1003	Rear Maint. Panel	19	CS1-2000	Exterior Door Assembly
3	CS1-1004	Left Panel	20	CS1-3001	HE Baffle
4	CS1-1006	Right Panel	21	CS1-3002	HE Tube Plate
5	CS1-1007	Panel Cover	22	CS1-3003	Top Link
6	CS1-1008	Rear Panel	23	CS1-3004	Bottom Link
7	CS1-1010	Blower Bracket	24	CS1-3018	Pump Mount
8	CS1-1017	Exhaust Motor Cover	25	CS1-3050	Slide Arm Connector Assembly
9	CS1-1024	Blocker Plate	26	CS1-3100	Actuator Tower Assembly
10	CS1-1025	Door Switch Bracket	27	CS1-3300	Ash Bin Assembly
11	CS1-1080	Back Up Hinge Assembly	28	CS1-4200	Auger Motor Bracket Assembly
12	CS1-1108	HE Air Deflector	29	CS1-4401	Auger Spacer
13	CS1-1350	Air Intake Tube Assembly	30	CS1-4500	Hopper Frame Assembly
14	CS1-1380	Intake End Assembly	31	CS1-5008	Exhaust Extension
15	CS1-1390	Sail Switch Assembly	32	CS1-9101	Fan Limit Control
16	CS1-1501	Hopper Top	33	CS1-9102	Outer Door Hinge
17	CS1-1505	Lid Switch Arm	34	CS1-9103	Outer Door Latch (<i>Male & Female</i>)
Item	Part Number	Description	Item	Part Number	Description
35	CS1-9104	Convection Blower	56	CS1-9446	Bronze Bushing
36	CS1-9105	1' x 12" x 20" Air Filter	57	CS1-9449	3/8" Coupler
37	CS1-9152	Top Panel Seal	58	CS1-9502	Exhaust Blower Gasket
38	CS1-9154	Hopper Seal	59	CS1-9503	Exhaust Motor
39	CS1-9155	Right Lid Hinge	60	CS1-9505	Snap Disc
40	CS1-9156	Left Lid Hinge	61	CS2-1400	Controller Assembly
41	CS1-9157	Lid Handle Latch	62	CS2-3200	Inner Fire Door
42	CS1-9158	Friction Support	63	CS2-3260	Door Handle Assembly
43	CS1-9204	Door Switch Magnet	64	CS2-3580	Igniter Assembly
44	CS1-9205	Door Switch Wired	65	CS2-5001	Exhaust Cover Plate
45	CS1-9301	Knife Actuator	66	CS2-5002	Exhaust Combustion Plate
46	CS1-9304	HE Tube Plate Gasket	67	CS2-5003	Exhaust Box Gasket
47	CS1-9309	Pot Actuator	68	CS2-5004	Exhaust Cover Plate Gasket
48	CS1-9351	Ignitor	69	CS2-5100	Exhaust Tube Assembly
49	CS1-9352	Head Brass Pin	70	CS2-5200	Exhaust Flange Assembly
50	CS1-9405	Lid Switch Cover	71	CS2-9321	Very High Temp Glass
51	CS1-9406	Lid Push Switch	72	CS2-9324	Rope Inner Door Gasket
52	CS1-9408	Hopper Compression Gasket	73	CS2-9327	Fiber Glass Door Gasket
53	CS1-9421	Spider Coupler	74	CS2-9448	Modified 1/2' Coupler
54	CS1-9444	Auger Motor	75	CS3-3900	Pot System Assembly
55	CS1-9445	Auger			

Burnpot Assembly Version 1

<u>Item</u>	<u>Part Number</u>	<u>Description</u>
1	CS1-3802	Ash Tray
2	CS1-3811	Slicer
3	CS1-3820	Burn Pot Assembly
4	CS1-3840	Removable Linear Assembly
5	CS1-3860	Pot Frame Assembly
6	CS1-3880	Clinker Breaker Assembly

Burnpot Assembly Version 2

1	CS1-3810	Slicer Assembly
2	CS1-3902	Ash Tray
3	CS1-3920	Burn Pot Assembly
4	CS1-3940	Removable Top Assembly
5	CS1-3980	Air Wash Assembly

Burnpot Assembly Version 3

1	CS3-3901	Removable Ramp
2	CS2-3902	Right Pin Hold-Down
3	CS2-3903	Left Pin Hold-Down
4	CS2-3904	Trap Door Hold-Up
5	CS2-3905	Trap Door Catch
6	CS3-3910	Re-Light Plate
7	CS2-3920	Burn Pot Assembly
8	CS2-3940	Pusher Assembly
9	CS2-3960	Pot Housing
10	CS2-3980	Flapper Door Assembly
11	CS2-3990	Door Pusher Assembly
12	CS1-9997	#4 Zinc Plated Washer
13	CS2-9391	Blind River 1/4" Mat. Thickness (Not Shown)

Burnpot Assembly Version 4

1	CS3-3901	Removable Ramp
2	CS3-3906	Pot Gasket
3	CS3-3910	Re-Light Plate
4	CS3-3920	Left Burn Pot Assembly
5	CS3-3930	Right Burn Pot Assembly
6	CS3-3940	Pot Pusher
7	CS3-3960	Pot Housing
8	CS3-3980	Flapper Door Assembly