

Fire Magic Grill 3324 and 3329 Parts List

| Item | Description | 3324 | | 3329 | |
|------|---|----------|------|----------|------|
| | | Part No. | Qty. | Part No. | Qty. |
| 1. | Stainless steel grill oven (optional) | 23733 | 1 | 3731 | 1 |
| 2. | Warming rack (optional) | 3673S | 1 | 3671S | 1 |
| 3. | Charcoal pan | 3304 | 2 | 3302 | 1 |
| 4. | Stainless steel cooking grids (set of 2 or 3) | 3543-S-3 | 1 | 3537-S-2 | 1 |
| 5. | Grill assembly | 3320-55 | 1 | 3325-55 | 1 |
| 6. | Crank | 3301 | 1 | 3301 | 1 |