

Fire Magic Grill 34-S2S1N-A Parts List

Item	Description
1.	TOP PANEL (STAINLESS STEEL)
or	TOP PANEL (PORCELAIN)
2.	18"X10" COOKING GRID (STAINLESS STEEL)
or	18"X10" COOKING GRID (PORCELAINIZED CAST IRON)
3.	FLAVOR GRID 7"
4.	FLAVOR GRID 10" (2)
5.	BURNER (6)
6.	AIR SHUTTER SPRING (6)
7.	AIR SHUTTER (6)
8.	ORIFICE (NAT GAS)
or	ORIFICE (PROPANE GAS)
9.	VALVE MANIFOLD W/ VALVE & REGULATOR
10.	BURNER MANIFOLD (3)
11.	15.5" FLEX TUBE ASSEMBLY
12.	34" FLEX TUBE ASSEMBLY
13.	48" FLEX TUBE ASSEMBLY
14.	CONTROL KNOB (3)
15.	IGNITOR ASSEMBLY
16.	GROUND WIRE
17.	ELECTRODE COLLECTOR ASSEMBLY
18.	DRIP TRAY
19.	DISPOSABLE DRIP TRAY LINER

With Back Burner

Item	Description
1.	OVEN HOOD W/ BACKBURNER (S.S. OR PORCELAIN)
2.	BACKBURNER ASSEMBLY
3.	TOP PANEL (STAINLESS STEEL)
or	TOP PANEL (PORCELAIN)
4.	18"x10" COOKING GRID (PORCELAINIZED CAST IRON) (3)
or	18"X10" COOKING GRID (STAINLESS STEEL) (3)
5.	FLAVOR GRID 7" (1)
6.	FLAVOR GRID 10" (2)
7.	BURNER (6)
8.	AIR SHUTTER SPRING (6)
9.	AIR SHUTTER (6)
10.	ORIFICE (NAT GAS)
or	ORIFICE (PROPANE GAS)
11.	BACKBURNER ORIFICE (NAT GAS)
or	BACKBURNER ORIFICE (PROPANE GAS)
12.	BURNER MANIFOLD (3)
13.	VALVE MANIFOLD W/ VALVE & REGULATOR
14.	48" FLEX TUBE ASSEMBLY
15.	34" FLEX TUBE ASSEMBLY
16.	15.5" FLEX TUBE ASSEMBLY
17.	ELECTRODE COLLECTOR ASSEMBLY
18.	BACKBURNER KNOB (1)
19.	CONTROL KNOB (3)
20.	IGNITOR GENERATOR
21.	DRIP TRAY
22.	DISPOSABLE DRIP TRAY LINER