

Fire Magic Grill A830S Parts List

Item	Description	Part No.	Qty.
1.	18x12 stainless cooking grid	3542-S-1	3
2.	18x10 stainless cooking grid	3543-S-1	1
3.	Flavor grid (set of 2)	3063-S-2	1
4.	Main burner	3042-50	2
5.	Heatshield kit	24177-05	2
6.	Silicone gasket	24177-06	2
7.	Infrared burner*	3060	1
8.	Charcoal burner	24133-31	1
9.	Thermometer with bezel	23305	2
10.	Oven lid (gas grill)	23729-54	1
11.	Oven lid (charcoal grill)	23727-54	1
12.	Oven lid handle w/ mounts (gas grill)	3735-27	1
13.	Oven lid handle w/ mounts (Charcoal grill)	24133-26	1
14.	Warming rack (gas grill)	3672S-M	1
15.	Warming rack (charcoal grill)	3681S	1
16.	Charcoal screen	3306-01	1
17.	Charcoal tray	3306-S	1
18.	Back burner*	24130-11H	1
19.	Back burner cover*	24148-010	1
20.	Rotisserie motor*	3600-02	1
21.	Rotisserie rod*	3603-30	1
22.	Meat holder (pair)*	3613	1
23.	Counterbalance*	3620E	1
24.	Grid lifter (equipped or optional)	3519	1
25.	Convertible regulator	PR-4	1
26.	Valve manifold w/ back burner	24330-22	1
or	Valve manifold w/o back burner	24330-24	1
27.	Control panel w/ back burner	24133-45	1
or	Control panel w/o back burner	24133-46	1
28.	Small knob	3016	2
29.	Large knob	3015	2
30.	Crank	23302	1
31.	Drip tray	3084	1
32.	Drip tray liner (set of 4)	3557	1
33.	Charcoal drip tray	3088	1

* Optional

‡ Not shown

Woodman's Parts Plus
www.woodmanspartsplus.com

Item	Description	Part No.	Qty.
34.	Folding shelf	24316-15R/L	2
35.	Paper towel holder assembly	25387-11	1
36.	Tool holder assembly‡	25387-12	1
37.	Door (left)	24370-19L	1
38.	Door (right)	24370-19R	1
39.	Door handle	3900-40	4
40.	Caster kit (set of 4)	3400-7	1
41.	Storage drawer	24370-31	1
42.	Propane regulator / hose assy.	5110-07	1
or	Natural Gas QD hose ‡	5110-03	1
43.	Propane tank tray (propane models only)	25386-21	1
44.	Wire harness assembly‡	24177-28	1
45.	Back burner electrode*‡	4199-52	1
46.	Main burner electrode ‡	3199-72	2
47.	Charcoal burner electrode	4199-52	1
48.	Natural gas orifice(s)‡	3001-42-2	1
49.	Natural back burner gas orifice*‡	3001-52-1	1
50.	Natural charcoal gas orifice(s)‡	3001-40-1	1
51.	Propane gas orifice(s)‡	3001-54-2	1
52.	Propane back burner gas orifice*‡	3001-59-1	1
53.	Propane charcoal gas orifice(s) ‡	3001-53-1	1
54.	Fire Magic® cookbook‡	3595	1
55.	Power supply w/ connector	24177-12	1
56.	12V / 10 watt halogen light bulb ‡	24187-15	2
57.	Light lens ‡	24187-26	2
58.	Lamp assembly ‡	24187-28	2
59.	Light switch	24182-46	1

* Optional
‡ Not shown