

Fire Magic Electric Grill E250 Parts List

Item	Part No.	Description
1.	3549	Cooking grids, 1 pair
2.	23115-01	Element
3.	23115-02	Inner liner kit
4.	23115-26	Handle assy
5.	23115-51	Oven lid assy
6.	3680	Warming rack
7.	23115-12	Digital thermometer
8.	23115-13	Thermometer harness (not shown)
9.	23115-07	Control panel w/ power cord & electronics
10.	23115-14	Meat probe
11.	3086	Drip tray
12.	23115-09	Bumpers, set of 4 *
13.	25115-015	Drop down shelf (2) †
14.	25115-03	Post assy †
15.	3604S	Rotisserie kit ‡
16.	3557	Drip tray liners, set of 4 ‡ (1 sample liner included)
17.	3642	Countertop cover (not shown) ‡
18.	5115-20	Pedestal cover (not shown) ‡