

1. GAS VALVE NATURAL LP	7529109 7529110
2. PILOT BURNER NATURAL (Manual) NATURAL (Piezo) LP (Manual) LP (Piezo)	7531111 7531113 7531115 7531116
3. THERMOGENERATOR	7533113/51827
4. IGNITOR - PIEZO MODELS	7592101
5. BURNER ORIFICE NATURAL (#50) LP (#56)	7535127 7535128
6. LOGS TOP BOTTOM	7583125 7583128
7. FRONT ACCESS COVER	3959133
8. SCREEN RAIL	3959125
9. SCREEN ROD*	3030126
10. SCREEN*	7554340
11. SCREEN KNOB*	7536236
12. SCREEN CLIPS**	7512135
13. BURNER TUBE ASSEMBLY	7540241
14. GRATE ASSEMBLY	7579135
15. ROCKER SWITCH	7522355
16. LIMIT SWITCH DISC	7522314

\*Two (2) required per fireplace model

\*\*Four (4) required per fireplace model