

# GBY536 Gas-Fired Fireplace

Item/Model Number	Part Number
1. TOP EXTRUSION (Hood) (1) POLISHED BRASS - PB LEFT RIGHT FRONT POLISHED CHROME - PC LEFT RIGHT FRONT BRUSHED BLACK - BK LEFT RIGHT FRONT Locking Extrusion Key*	5071123 5071124 5071125 5071148 5071149 5071150 5071142 5071143 5071144 7512215
2. BOTTOM EXTRUSION (1) POLISHED BRASS - PB LEFT RIGHT FRONT POLISHED CHROME - PC LEFT RIGHT FRONT BRUSHED BLACK - BK LEFT RIGHT FRONT	5071126 5071127 5071128 5071151 5071152 5071153 5071145 5071146 5071147

\* Two (2) required per fireplace model

Continued on Next Page

Item/Model Number	Part Number
3. GLASS PANELS PLAIN GLASS ENDS* FRONT BEVELED GLASS ENDS* FRONT TINTED GLASS ENDS* FRONT	           7540464 7540465  7540468 7540469  7540474 7540475
4. GRATE	7072128
5. BOTTOM 24" LOG*	2065101
6. LOG TOP (12Y)*	2349103
7. TOP LOG (12DL)*	2349104
8. BURNER	5071134
9. THERMAL VENT DAMPER (TVD6)	5187101
10. BURNER ORIFICE NATURAL (#30) LP (#48)	 7535149 7535146
11. GAS VALVE — ROBERTSHAW NATURAL LP ASSEMBLY	 7529109 7529110
12. GAS VALVE — HONEYWELL NATURAL LP ASSEMBLY	 7529129 20000720
13. PILOT BURNER — ROBERTSHAW NATURAL LP	 7531117 7531118
14. PILOT BURNER — HONEYWELL NATURAL LP	 7531127 7531128
15. THERMOGENERATOR (42")	5075149
16. PIEZO IGNITOR	7592101
17. ON-OFF-RS SWITCH	7522355
18. MICROSWITCH	7540214
19. THERMAL DISK (Manual Reset)	7522428
20. TRANSFORMER	7522409
21. ACCESS DOOR COVER	5033155
22. BURNING EMBERS	7060109
23. VOLCANIC ROCK	7060151
24. SCREEN ROD FRONT* END	 5071139 5071157
25. SCREEN**	7554299

\* Two (2) required per fireplace model

\*\* Six (6) required per fireplace model