

ITEM	PART #	DESCRIPTION
	350591	GF 400 DV Sebago, MB
	350592	GF 400 DV Sebago, BB
	350593	GF 400 DV Sebago, IV
	Accessories	
	155351	Conversion Kit, LP
	155352	Conversion Kit, NG
	155371	Variable Speed Blower
	156000	Variable Speed Blower Kit, after serial no. 30000
	220617	Blower Snapstat (3/4 inch, 120 - 10)
	155554	Blower Misc. Kit
	155375	Brick Panel Kit
	155377	Screen
	750304	Floor Bracket Kit
		Short Leg Kits available, see accessories
	154923	Floor Bracket Kit, Short Legs
1	220624	Air Divider
2	129126	Simpson DuraVent Collar
3	129118	Collar Gasket
4	220584	Switch Box
5	220613	Rating Plate
6	129159	Lanyard
7	10391892	Left Side Plate, MB
	10391885	Left Side Plate, J Iron
	10421727	Left Side Plate, BB
	10421729	Left Side Plate, IV
	10421732	Left Side Plate, GN
	10421746	Left Side Plate, JIE
	10421747	Left Side Plate, BRM
	10421748	Left Side Plate, BLM
8	22055892	Rear Shroud, MB
	22055885	Rear Shroud, JI
9	10396392	Base Plate, MB
	10396385	Base Plate, J Iron
	10396327	Base Plate, BB
	10396329	Base Plate, IV
	10396332	Base Plate, GN
	10396346	Base Plate, JIE
	10396347	Base Plate, BRM
	10396348	Base Plate, BLM
11	222263	Valve - NG
	220562	Regulator Tower, NG, 50% Turn down
	220519	Regulator Tower, LP, 50% Turn down
12	129129	Elbow, 3/8" Brass
13	129154	Terminal Block
14	10192592	Leg, MB
	10192585	Leg, J Iron
	101966	Leg, BB
	102251	Leg, IV
	10192532	Leg, GN

ITEM	PART #	DESCRIPTION
	10192546	Leg, JIE
	10192547	Leg, BRM
	10192548	Leg, BLM
15	220614	Bracket, Terminal Block
16	221769	Main gas Line
	156037	Main Gas Line Replacement Kit
17	129668	Orifice Holder Assembly
18	12972592	Glass Frame
	155553	Glass w/gasket
	220567	Glass Pane, Ceramic
	129124	Glass Gasket 7/16 " price per foot (8 ft.required)
19	15565492	Front Door Assembly, MB
	15565485	Front Door Assembly, JI
	155660	Front Door Assembly, BB
	155672	Front Door Assembly, IV
	155666	Front Door Assembly, OG
	156147	Front Door Assembly, JIE
	156372	Front Door Assembly, BRM
	156501	Front Door Assembly, BLM
20	10371292	Keeper, Door Latch
21	22058592	Valance, MB
	22058585	Valance, JI
21	22118892	Control Door, MB, Front Mounted Valve
	22118885	Control Door, JI, Front Mounted Valve
22	220603	Door Latch
23	10421692	Right Door, MB, see # 19
	10421685	Right Door, Iron
	10421627	Right Door, BB
	10421629	Right Door, IV
	10421632	Right Door, GN
	10421646	Right Door, JIE
	10421647	Right Door, BRM
	10421648	Right Door, BLM
24	155378	Log Set, Complete
	220645	Rear Log
	220646	Left Log
	220647	Right Log
	220648	Middle Log
	220701	Cross-over Log
	220702	Embers, 4 oz.
25	10391992	Right Side Plate, MB
	10391985	Right Side Plate, J Iron
	10421827	Right Side Plate, BB
	10421829	Right Side Plate, IV
	10421832	Right Side Plate, GN
	10421846	Right Side Plate, JIE
	10421847	Right Side Plate, BRM
	10421848	Right Side Plate, BLM
26	220642	Air Intake Gasket
27	220602	Air Intake Restrictor
28	220644	Air Shutter Gasket

ITEM	PART #	DESCRIPTION
29	129670	Pilot Assembly Gasket
30	220546	Pilot Assembly Spacer
31	129471	Pilot Assembly, w/NG orifice
	220384	Pilot Hood Only, pop top pilot assembly
	129472	Pilot Orifice NG # 51
	129473	Pilot Orifice LP, # 30
	129152	Jam Nut-Orifice Holder
	129446	Pilot Line w/ Fittings
	129766	Thermocouple
	129765	Electrode
	3094527	Thermopile
32	155336	Burner Assembly
33	22058292	Burner Skirt, MB
	22058285	Burner Skirt, JI
34	220565	Exshhaust Baffle
35	220563	Exhaust Restrictor
36	220583	Exhaust Restrictor Gasket
37	129717	Firebox Assembly
	221960	Firebox Assembly, Above Serial No. 30,000
38	22009192	Latch Assembly
39	129319	Relief Door Gasket
40	129640	Relief Door
41	10396292	Top Plate, MB
	10396285	Top Plate, J Iron
	10396227	Top Plate, BB
	10396229	Top Plate, IV
	10396232	Top Plate, GN
	10396246	Top Plate, JIE
	10396247	Top Plate, BRM
	10396248	Top Plate, BLM
42	129499	Relief Door Guide
43	155653	Heat Exchanger, (4)
44	220596	Inner Shroud, Right
45	220597	Inner Shroud, Left
46	3902576	Ignitor Bracket
47	3902573	Ignitor
48	220641	Burner Orifice, NG #33
	220638	Burner orifice, LP # 1.65
49	220790	Primary Air Shutter
50	10421592	Left Door, MB, see # 19
	10421585	Left Door, J Iron
	10421527	Left Door, BB
	10421529	Left Door, IV
	10421532	Left Door, GN
	10421546	Left Door, JIE
	10421547	Left Door, BRM
	10421548	Left Door, BLM
51	220709	Rheostat Knob
52	220703	Rocker Switch, (2)
53	220700	Rheostat
54	220717	Retaining Collar

ITEM	PART #	DESCRIPTION
55	118023	Fender Washer
56	117975	Wingnut, (3)
57	155397	Wire Harness
	156034	Wire Harness, Serial No. after 30,000
58	221176	Conrtol Door Hinge
	156003	Control Door Hrd. Kit, Use on Serial No.'s 34496 or below
59	117117	Bolt, M6 x 20
60	118040	Spacer, .375 o.d. x 3.172
61	118029	Fender Washer, .250 x 1.50 dia
62	117955	Hinge Bolt, M6 x 100,
63	117994	Spacer, .250 x .50, .250 Alum.
	220733	Wire Harness Retainer
	118006	Terminal Block, Ceramic
	155557	Wire, Terminal Block Jumper, 3 "
	155380	Misc. Kit

WoodmansPartsPlus.com