

# HEB30

Item/Model Number		Part Number		
1.	LOG FRONT	17425		
2.	LOG REAR	50423		
3.	LOG RIGHT	17429		
4.	LOG LEFT	06498		
5.	LOG SET COMPLETE	17420		
6.	CERAMIC BURNER SET	17385		
7.	BURNER FRONT	52851		
8a.	ORIFICE - MAIN BURNER HA #42	50992		
8b.	ORIFICE - MAIN BURNER NAT. #40	52911		
8c.	ORIFICE - MAIN BURNER LP #55	50998		
9a.	ORIFICE - FRONT BURNER HA #54	51918		
9b.	ORIFICE - FRONT BURNER NAT. #53	51930		
9c.	ORIFICE, FRONT BURNER LP #71	51702		
10.	PIEZO IGNITOR	50932		
11.	ELECTRODE, IGNITOR	50931		
12.	TUBING - PILOT W/FITTINGS	53309		
13.	WIRING ON/OFF SWITCH ASSEMBLY	52817		
14.	CORD, POWER 18/3 HPN 6 FEET	51865		
15.	DRAFT HOOD ASSEMBLY	17010		
16.	HINGE	52356		
17.	GLASS SIDE C/W GASKET LEFT OR RIGHT	55042		
18.	GLASS FRONT C/W GASKET	53433		
19.	GLASS GASKET	57310		
20.	FRAME - BAY WINDOW EXTERIOR	53360		
21.	FRAME - BAY WINDOW INTERIOR	52819		
22.	REFRACTORY LINING SET	52642		
23.	SWITCH, FAN SPEED CONTROL	51738		
24.	SENSOR, FAN	51704		
25.	KNOB, BLACK	51882		
26.	FAN, C/W BRACKET	53311		
27.	EMBER MATERIAL	51915		
28.	LOUVRE, BOTTOM ASSEMBLY	52820		
29.	SENSOR, SPILL SWITCH (NOT SHOWN)	51866		
Model	Thermocouple/Thermopile	Burner c/w Ceramic	Valve	Pilot
HEB30RN	51827 or 7533113	52868	52779	51826
HEB30RP	51827 or 7533113	52869	51835	52741
HEB30TN	52684	53643	53447	52683
HEB30TP	52684	53643	53445	52682