

HE30

Item/Model Number	Part Number
1. LOG - FRONT	17425
2. LOG - REAR	50423
3. LOG - LEFT	06498
4. LOG - RIGHT	17429
5. LOG - SET COMPLETE	17420
6. FRONT BURNER HOOD ASSEMBLY	17405
7. CERAMIC BURNER SET	17385
8a. BURNER HOUSING C/W CERAMICS (TN)	52833
8b. BURNER HOUSING C/W CERAMICS (TP)	52834
8c. BURNER HOUSING C/W CERAMICS (RN)	52835
8d. BURNER HOUSING C/W CERAMICS (RP)	52836
9. FRONT BURNER	52839
11a. ORIFICE - MAIN BURNER NAT. #40	52911
11b. ORIFICE - MAIN BURNER LP #56	50999
11c. ORIFICE - MAIN BURNER NAT. HA #42	50992
12a. ORIFICE - FRONT BURNER NAT #53	50994
12b. ORIFICE - FRONT BURNER LP #69	52980
12c. ORIFICE - FRONT BURNER NAT. HA #54	51918
13a. IGNITOR ELECTRODE TN/TP	52465
13b. IGNITOR ELECTRODE RN/RP	50931
14. ELECTRODE CABLE TN/TP	51850 or 7522432
15a. PILOT SUPPLY LINE TN/TP WITH FITTINGS	53211
15b. PILOT SUPPLY LINE RN/RP WITH FITTINGS	53309
16. GLASS & GASKET	51735
17. GLASS GASKET ONLY	N/A
18. SPEED CONTROL	51738
20. SENSOR, FAN	51704
21. ELECTRICAL CODE HPN 18/3 WIRE	51865
22. EMBER MATERIAL	51915
23. LAVA ROCK	50924
24. WIRING HARNESS FOR VENT SAFETY (U.S. UNITS ONLY) SPILL SWITCH ASSY	52549
25. SENSOR VENT SAFETY (USA)	51866
26. BRACKET, VENT SAFETY (USA)	17460
27. FRAME, GLASS	17041
28. VALVE COVER WITH IGNITOR	51851

Model	Thermocouple	Thermopile	Valve	Pilot Assembly
HE30TN	N/A	52684	52685	52683
HE30RN	51827 or 7533113	N/A	52779	51826
HE30RNHA	51827 or 7533113	N/A	52779	51826
HE30TNHA	N/A	52684	52684	52683
HE30TP	N/A	52684	52686	52682
HE30RP	51827 or 7533113	N/A	51835	52741
HE30TPB	N/A	52684	52686	52682
HE3TNB	N/A	52684	52685	52683
HE30RNB	51827 or 7533113	N/A	52779	51826
HE30RPB	51827	N/A	51835	52741