

JA461

REF #	Part #	Part Description	QTY
1	50001074	CABINET BOTTOM ASSY	1
2	50000974	CABINET END LEFT	1
22	50000984B	SHELF FRONT S/S RIGHT	1
23	50000986B	SHELF FRONT S/S LEFT	1
24	50000816	IGNITOR KIT (Push button IS included)	1
25	50001328	CONTROL KNOB	4
26a	50001413B	SHELF TOP	1
26b	50001412B	SHELF S/S - SOLID	1
27	50000826B	SHELF INSERT	1
28	50003514	LID ASSY REAR - Also send p/n 50000355.	1
29	50000877	HEAT PLATE ENAMEL	4
30	50000802	WARMING RACK ENAMEL	1
31	50000313	DOOR HANDLE	1
32	50001226	COOKING GRIDS (PACK OF 3)	1
33	50000177	LID BUMPER	4
34	50000804	REGULATOR LP	1
35	50000355	PIVOT PIN & BOLT SET - Send with lid assembly	1
36	50001399	LID ASSY FRONT - Also send p/n 50000355.	1
37	50001643	TEMPERATURE GAUGE	1

JA461

38	50000915	CONNECTOR HOSE NG	1
39	50000198	12 HOSE NG	1
40	50001327	KNOB BEZEL	4
N/A	50000882	HARDWARE BAG	1
N/A	50003432	CONSOLE REPAIR KIT	1
3	50002153	DOOR ASSY	1
4	50000978	CABINET END RIGHT	1
5	50001076	PANEL - BACK	1
6	50000975	CABINET TOP	1
7	50000797	DRAWER SUPPORT RIGHT	1
8	50000798	DRAWER SUPPORT LEFT	1
9	50000822	GREASE PAN	1
10	50000983	CABINET END - WRAP	1
11	50001167	BASE ASSY	1
12	50001234	CONSOLE	1
13a	50000801	VALVE ASSY - LP	1
13b	50000850	VALVE ASSY - NG	1
14	50003100	BURNER TUBE with SHORT ELECTRODE	2
N/A	50003133	BURNER TUBE with LONG ELECTRODE	2
N/A	50003457	BURNER REPAIR KIT	4
15	50000892	BURNER GASKET	4
16	50000879B	FLASH TUBE	1

JA461

17	50000431	ELECTRODE MAIN SHORT	2
18	50000523	ELECTRODE MAIN LONG	2
19a	50000809	CASTER (SCREW IN) - Threaded or pop-in?	4
19b	50000090	CASTER (POP IN) - Threaded or pop-in?	4
N/A	50001324	CASTER NUT REPAIR KIT	1
20	50001418	SUPPORT SHELF BLACK - Left rear & right front	2
21	50001419	SUPPORT SHELF BLACK - Right rear & left front	2

Woodmanspartsplus