

LIST OF REPAIRS FOR JEWEL CAST RANGES

1	Leg. State if Range has leg frame or not.	85	Extension Shelf for Right End of Square Range. (Not shown; state if drop shelf with bracket, or stationary shelf).	139	"	End—Right.
2	Short Leg Frame, Right or Left. Not shown. For Ranges without low closet.			140	"	" —Left.
3	Long Leg Frame, Front or Back. Not shown. For Ranges without low closet.	89	Shaking Coal Grate or Bottom Grate. State whether flat grate, Jewel grate, or dock-ash grate.	141	"	Door—Right.
4	Main or Leg Bottom.			142	"	" —Left.
5	Oven Bottom.	90	Grate Frame.	143	"	Front or Door Frame.
6	" Back.	91	Poker Drop.	144	"	Door Panel, Nickerled.
7	" Front.	92	Coal Feed Door.			
8	" Top.	93	" " Sliding Damper.			
9	Left End.	94	Ash Catch.			
10	Oven Flue Stopper.	95	Fire Box Lining—Front End.			
11	Flue Door, under Oven Shelf.	96	" " —Back "			
12	Main Front, or Oven Door Frame.	97	Grate Slide or Draw Center of Coal Grate.			
13	Main Back.	98	Draw Bar for Shaking and Draw Center Grate.			
14	Kicker, or Oven Door Opener.	99	Shaker.			
15	Outside Oven Shelf.	100	Slide for Wood Grate. (Not shown).			
16	Shelf Name Plate.	101	Water Front Caps.			
17	Bottom Flue Strip.	102	Grate Cap. (On outside end of fire box, and not shown).			
18	Hearth Top.	103	Follower.			
19	Ash Pit.	104	" Holder.			
20	Swing or small Slide Hearth. (Not on this Range).	105	Oven Front Horn or Draw Grate Support.			
21	Ash Pan.	106	Ash Pit Strip—Front or Right.			
22	Wood Grate, or False Bottom. (Not shown).	107	" " —Back or Left.			
23	Wood Fire Door.	108	Oven Door Ventilating Register (Not shown).			
24	Wood Fire Door Guard or Lining.	109	Handle for Reservoir Rolling Damper.			
25	Fire Box Back Lining—Right	110	Handle for Top or Oven Rolling Damper.			
26	" " —Left	111	Hook for Top or Oven Rolling Damper.			
27	" " —Center	112	Flue Back.			
28	(Not in this Range).	113	"T" Shelf—Front.			
29	Center Post.	114	" " —Back.			
30	Front Top.	115	" " —Sliding Damper.			
31	Back Top or Collar Top.	116	Swinging Teapot Shelf.			
32	Top Feed Piece.	117	High Closet Flue Pipe Back.			
33	" " Guard or Lining.	118	" " Front.			
34	Mica Door.	119	" " Bonnet.			
35	" " Sliding Damper.	120	" " Pipe Collar.			
36	Mica Frame, or Holder.	121	" " Bottom or High Shelf Top.			
37	Fire Box Front Lining.	122	" " Cylinder Door.			
38	Wood Pocket.	123	" " Handle.			
39	Top Rolling Damper.	124	" " Panel, Nickerled.			
40	Reservoir Rolling Damper.	125	" " Tile. (Not shown).			
41	Tank Casing—Left.	126	High Closet Cylinder Spring Cap—Right.			
42	" " —Right.	127	High Closet Cylinder Spring Cap—Left. (Not shown).			
43	Oven Door.	128	High Closet Cylinder End—Right.			
44	Oven Door Nickerled Panel.	129	High Closet Cylinder End—Left.			
45	" " Tile.	130	High Closet End—Right.			
46	" " Knob.	131	" " —Left.			
47	Oven Rack, or Slide.	132	" " Back—Right.			
48	Towel Rod.	133	" " —Left.			
49	Right End Plate below Tank Casing, or full right end on Square Range.	134	" " Corner Strip.			
50	Tank Rest—Short.	135	" " Top.			
51	" " —Long.	136	" " or High Shelf Top Ornament.			
52	Tank Cover—Back.	137	Low Closet Bottom.			
53	" " —Front.	138	" " Back.			
54	Tank—Copper or Gray Enamelled Iron.					
55	Stationary Tank Top.					
56	Tank Casing—Bottom.					
57	" " —Front Cheek.					
58	" " —Back "					
59	Short Center.					
60	"T" Center.					
61	Cut Long Center.					
62	Covers.					
63	Number Plate.					