

Key No.	Left Hand	Right Hand	Description
1	10110500	10110500	Fender Washer $\frac{5}{16}$ " I.D. x 1" O.D. (2 Req.)
2	10104900	10104900	Screw, Thread Cutting, Hex Washer Hd $\frac{1}{4}$ -20 x $\frac{3}{4}$ " (2 Req.)
3	20102200	20102200	Bracket, Baffle (3 Req.)
4	10105300	10105300	Nut, Hex $\frac{1}{4}$ -20 (14 Req.)
5	20105900	20105900	Baffle, Smoke (2 Req.)
6	20102640	20102640	Top Brick Retainer, Rear
7	20102650	20102650	Top Brick Retainer, Side (2 Req.)
8	10100800	10100800	Fire Brick 9" x 4 $\frac{1}{2}$ " x 2" (4 Req.)
9	10100700	10100700	Fire Brick 9" x 6" x 2" (18 Req.)
9	10100700	10100700	Fire Brick 9" x 6" x 2" (4 Req.)
10	10116200	10116200	Fire Brick 12" x 6" x 2" (12 Req.)
11	30103000	30103000	Tube Retainer
12	20108400	20108400	Connecting Rod Ass'y (Includes 2 $\frac{5}{16}$ " Locknuts)

Key No.	Left Hand	Right Hand	Description
13	10122400	10122400	Coal Grate (2 Req.)
14	10122500	10122500	Grate Frame (2 Req.)
15	10122900	10122900	Handle, Coal Grate
16	10123200	10123200	Coal Grate Ass'y
17	30103600	30103600	Secondary Air Tube
18	10110700	10110700	Gasket, Secondary Air Tube (2 Req.)
19	20107003	20107003	Latch, Ash Pan
20	10105000	10105000	Screw, Machine, Rd Hd 1/4-20 x 3/4" (4 Req.)
21	20107503	20107503	Ash Pan Ass'y
22	30300603	31300603	Base, Weldment
23	20104903	20104903	Fire Door Ass'y
24	10139700	10139700	Door Latch
25	30107003	30107033	Firebox
*	10100900	10100900	Wood Grates (3 Req.)

Key No.	Part No.	Description
1	10140700	DS102 Solenoid
2	10120720	DS102 Micro Switch (OBSOLETE)
3	10120722	DS102 Circuit Board
•	10120700	DS102 Assembly