

Ref.	Part [®]	Description
1	5665	Legs
2	11313	Bottom
3	11314	Right Side
4	11315	Left Side
5	11316	Front
6	11317	Back
7	11318	Top
8	11319	Hopper Lid
9	11320	Fire door
10	11321	Ash Door
11	11375	Front part of Hopper
12	11322	Back Part of Hopper
13	11323	Right Part of Hopper
14	11324	Left Part of Hopper
15	11325	Firebox Vase
16	11326	Bottom Grate
17	11327	De Ash Grate
18	11328	Slide For Secondary Air
20	11309	Ash Pan
21	11310	Bottom radiation Shield
22	11311	rear Radttaton Shield
23	492	Door Latch
24	6087	Secondary Air Guide
25	4673	Tool for hopper: lid / Ash pan
26	5625	Shaker Handle / Hook

Ref.	Part#	Description
27	2508	Slicing Knife
28	10646	Glass Clips
30	5271	Gasket for Glass 5mm
31	11329	Gasket for hopper lid 12mm
32	11329	Gasket for glass lid 12mm
33	11329	Gasket for ash door lid 12mm
34	11329	Gasket for vase lid 12mm
35	11337	Glass
36	11243	Door Handle
37	11243	Door Handle
38	6113	Washer (for legs)
39	5714	Thermostat
40	2321	Knob for Thermostat
41	6113	Washer (for Connecting Rod)
42	5610	Connecting Rod
43	4821	Nut for Legs 8M
44	11339	Spacer for Door Latch
45	11198	Knob for Secondary Air Intake
46	11340	Hinge Pin
47	11410	Washer for Secondary Air Intake
48	6079	Rod Assembly for Secondary Air
49	5713	Nuts for Rear Radiation Shield
50	11408	Leg Clip
51	11409	M5 Bolts for Glass Clips