

PARTS LIST

MAIN ASSEMBLY

Part #	Description	Part #	Description
1)	948-045 Chain		(Optional)
2)	948-025 Spring	42)	910-331/P Fan Motor (120 V)
7)	910-428 Duplex Receptacle	432-966	Fan Switch Assembly (120 Volts) (Optional)
8)	910-429 Box - Receptacle	43)	910-813 Power Cord (120 Volts)
9)	910-430 Cover - Receptacle	46)	910-330 Fan Speed Control Switch
10)	904-687 Clamp Connector	47)	904-586 Knob - Speed Control
14)	510-026 Hinge Bracket - Left/Right	49)	910-142 Thermodisc - Fan Auto On/ Off
15)	948-253 Door Handle	904-713	U-clip at louver
20)	510-033 Top Nailing Strip		
22)	510-153 Baffle Plate	50)	510-994 Rigid Pipe Adaptor
23)	510-011F Standoff - Top	946-556	Heat Wave Duct Kit (Optional)
24)	511-044 Standoff - Side/Back	89)	946-004 Junction Box
27)	* Outer Flue Collar	90)	946-000 Round Duct Adaptor
28)	* Inner Flue Collar Assy	91)	946-002 Round to Oval Adaptor
30)	* Gasket for Flue Collar	92)	946-001 Oval Duct Adaptor
31)	* Flue Mounting Plate	93)	946-007 Angle Bracket
513-901	Brick Panel Set - Standard Brown	94)	946-517/P Fan Assembly - Heat Wave
513-902	Brick Panel Set - Standard Red	95)	946-006 Grill Plate - White
513-903	Brick Panel Set - Herringbone Brown	96)	946-005 Wall Adaptor Plate - White
33)	* Brick Panel - Back	97)	910-417 Knob - White
34)	* Brick Panel - Left	98)	910-366 Switch Cover Plate - White
35)	* Brick Panel - Right	99)	910-412 Fan Speed Controller
511-031	Brick Clips (each)	100)	910-367 Box - Plastic Switch Receptacle
432-967	Burner On/Off Switch Assy	102)	946-010 Flexible Air Duct
38)	910-241 Switch - Burner On/Off	946-038	Insulation 6" Dia. x 24"
910-899	Wire Harness-Valve to Burner	946-570	Heat Release Duct Kit (Optional)
432-917	Fan Assembly 120V	108)	910-165 Fan (120 V)
		109)	946-000 Flexible Air Release Duct
		918-521	Manual
		514-969	Conversion Kit - NG to LP

BURNER ASSEMBLY & LOG SET

Part #	Description
513-574/P	Valve Assy - Natural Gas
513-576/P	Valve Assy - Propane
52) *	Valve Tray - NG/LP
53) 430-055	Gasket - Valve Access Plate
54) 910-421	Pilot ON/OFF 3"
	Extension Knob
55) 910-422	HI/LOW 3"
	Extension Knob
56) 910-190	Piezo Ignitor
57) 910-478	SIT Valve - NG/LPG
58) *	Valve Bracket
59) *	Firebox Base
66) 910-038	Pilot Assy - S.I.T. - 3 Flame NG
910-039	Pilot Assy - S.I.T. - 3 Flame LP
67) *	Pilot Holder
68) W840470	Pilot Assembly Gasket
904-240	Orifice #37 - Natural Gas
904-390	Orifice #52 - Propane
936-170	Orifice Gasket
910-036	Pilot Orifice NG
910-037	Pilot Orifice LP
79) 512-535	Burner Assy
82) 511-030	Burner Grate Assy
83) 430-101	Rear Log Support
	Bracket
84) *	Deflector
85) 512-930	Log Set

*Not available as a replacement part.

PARTS LIST

REGENCY® FLUSH FRONT ACCESSORIES

Part #	Description	Part #	Description
132) 512-518	Flush Door Assembly	150) *	Flush Glass Trim-Gold
510-920	Flush Louvers - Gold/Black	904-196	Magnet (1" round)
510-922	Flush Louvers - Black	510-947	Flush Glass Trim - Steel (Set)
510-923	Flush Louvers - Steel/Black	152) *	Flush Glass Trim
133) *	Flush Louver Assy-Top	904-196	Magnet
134) *	Flush Louver Assy-Bottom	510-986	Finishing Trim - Black
135) 940-090/P	Glass (Flush)	157) *	Finishing Trim Left
136) 936-155	Glass Gasket (Tadpole)	158) *	Finishing Trim Top
904-691	U-Clip	159) *	Finishing Trim Right
146) *	Barcelona Assy - Black	161) 948-216	Regency® Logo Plate
148) *	Barcelona Louver Assy-Black		

*Not available as a replacement part.

REGENCY® BAY FRONT ASSEMBLY

Part #	Description	Part #	Description
780-931	Bay Front Complete	112) *	Bay Front Trim - Top/Bottom
103) 940-092/P	Side Glass	780-934	Bay Door Trim - Gold
107) 936-243	Glass Gasket	113) *	Bay Door Trim-Gold-Bottom
108) 940-094/P	Center Glass	114) *	Bay Door Trim-Gold-Top
		510-988	Bay Louvers - Black
		510-990	Bay Louvers - Gold/Black
		510-993	Bay Louvers - Steel/Black
		115) *	Bay Louver Assy-Top
		116) *	Bay Louver Assy-Bottom
		117) 904-196	Magnet (1" round)
		120) *	Flush Glass Retainer Bracket
		122) 948-216	Regency® Logo Plate

*Not available as a replacement part.