

ITEM	Description	PART NUMBER
1	Hopper Assembly	1-10-73329
		1-10-08224A
2	Hopper Lid Assembly - Swell latch	1-10-73333A
	Hopper Lid Assembly - Spring Latch	1-10-73491A
	Swell latch	1-00-199110
	Spring Catch	3-31-00927
	Hopper Muffler and Fittings	1-00-18188618
	Hopper lid catch	2-00-72188B
	Gasket, Hopper Lid	1-00-00248
3	Fan Control / High limit	3-20-23139
4	Combustion Blower	3-21-08839
	Comb blower heat shield	2-00-73339
	Mounting Plate	1-10-73416
	Fan Blade, 5" Single Paddle (Combustion Blower)	3-20-40985
	Fan Blade, 5" Double (high altitude)	3-20-502221
	Fan Blade, Feed Motor	3-20-09302-3
5	Toggle Switch - 3 Speed	3-20-70020
6	Filter box kit	1-00-20201
7	Bottom Cover	2-00-73338-18S
		2-00-73340-18S
8	Ash Door	1-10-73323-18A
9	Top Cover	2-00-73411-18S
		2-00-73412-18S
10	Shaker Cover	2-00-73335-18S

ITEM	Description	PART NUMBER
11.1	Air Intake Damper Assembly	1-10-06466W
11.2	Air Intake Weldment	1-10-773843
11.3	Feeder Weldment	1-10-677150

11.4	Slide Plate Assembly	1-10-08037
11.5	Pusher Arm Assembly	1-10-08048
11.6	Feed Cover and Gasket	1-00-677152
11.7	Auger Assembly	3-50-00465
11.8	Cam Bearing	3-31-3014
11.9	Bearing Flange w/Hardware	1-00-04035
11.10	Bracket, Gear Motor	1-00-01534
11.11	Gear Motor, 6 RPM	3-20-09302
11.12	Cast Cam Block	3-00-00153
	Feeder Repair Kit	1-00-677150
	Gasket Feeder Air Intake	3-44-72224-6

ITEM	Description	PART NUMBER
12.1	Pellet Feeder Gear Motor, 10 RPM	3-20-02524
12.2	UL Feeder Cam	3-31-3014
12.3	Feeder Air Crossover Kit	1-00-67900
	9MM Silicone Tube	1-00-511427
12.4	Pellet Air Intake Assembly	1-10-06810A
12.5	Gasket Feeder Air Intake	3-44-72224-6
12.6	UL Feeder Air Intake	1-10-72222
12.7	Gasket Ultra Air Intake	3-44-677160-10
12.8	Ultra Feeder Weldment	1-10-72226S
12.9	UL Feeder Pusher Arm	1-10-677187W
12.10	Fines Deflector	2-00-677138-10
12.11	Gasket, UL Feeder Cover	1-00-677122
12.12	Slide Plate Assembly	1-10-677121A
12.13	UL Feeder Auger Assembly	3-50-00565
12.14	Bearing Flange w/Hardware	1-00-04035
12.15	UL Feeder Gear Motor Bracket w/Grommet	1-00-247406
12.16	UL Feeder Cam Block	3-00-677154
	Gasket, Hopper Throat	3-44-677185

ITEM	Description	PART NUMBER
	A/C double Pole relay	3-20-38056
	Arrow Burn Pot Scraper	2-00-773850-10
	Ash Pan	1-10-73351
	Battery back-up	3-20-512
	Brick Ledge	1-10-73347W
	Fire Brick 12 x 6 x 1.25"	3-40-86125
	Burn Pot Weldment	1-10-73546A
	Ceramic Insert	3-20-05238-10
	Clean Out Cover	1-00-06623
	Igniter Cradle Assembly	1-00-06620
	Thumb Screw	3-31-782108-10
	Gasket, Ceramic Insert Plate	3-44-724114
	Gasket, Burn Pot	1-00-07381
		3-44-724115
	Flame Guide	3-00-08534
	Flame guide insulator	3-44-35263
	Cable 2 Pair twisted cat 3 (50' for wall control)	3-20-02583
	Circuit Board	1-00-05888
	Circuit Plate, studded w/label	1-10-07330
	Control Knob/ Shaft	1-00-015605
	Fuse, 6 AMP	3-20-49447-5
	Circuit breaker 10 Amp (orange - on/off switch)	3-20-334110
	Circuit breaker harness - to control board	3-20-04947
		3-20-73369
	Differential Pressure Switch	3-20-6866
	Distribution Blower assembly 1000 Cfm	1-10-01006
	Air filter - 20 x 20 x 1	3-40-20201-12
	Blower assembly 1450 Cfm	1-00-00862
	Blower assembly 1638 Cfm	3-21-19599
	Distribution Blower mounting bracket	2-00-73430B
	Distribution Blower (motor only) 1000 cfm	3-20-36648
	ESP (Exhaust Sensing Probe)	3-20-11744
	ESP (Exhaust Sensing Probe)	3-20-00844
	Gasket, Chain shaker	3-44-08100-2
	Heat exchanger baffle - bottom	2-00-73314
	Heat exchanger baffle - top	2-00-73418
	Ignition Air Pump (Pressure Igniton)	3-20-02679

ITEM	Description	PART NUMBER
	Igniter Element	3-20-677200
	Igniter Element (Pressure Ignition)	3-20-00450
	Inner Ash door Assembly	1-10-73321A
	Gasket, 1/4" Rope Black w/PSA (Glass)	1-00-2312
	Inner ash door gasket	1-00-00539
	Inner ash door glass	3-40-5555
	Inner Ash Door Hinge	1-10-08735W
	Inner ash door spacer set w/gasket	1-00-232074
	Junction box harness	3-20-04948
	Low fuel sensor	4-20-03835
	Outside Air Vent Assembly	1-10-09542
	Flex pipe 2-3/4" (12-1/2")	2-00-08544
	Flex pipe 2-3/4" (25')	2-00-08545
	Terminal block for power supply - 3 Position	3-20-03018
	Thermostat extension 4 Pole	3-20-04946
	Thermostat (wall control)	3-20-08101