

Pel Pro Home Heaters Parts List

Part No.	Description
KS5150-1450	Fresh Air Intake Kit 3'
KS5150-1460	Fresh Air Intake Kit 10'
KS5130-1480	Hopper Extension—12"
KS5130-1490	Hopper Extension— 24"
KS5120-1370	Wall Thermostat Kit Assembly—F
KS5010-1010	Auger Motor Assembly
KS5010-1020	Auger Shaft Assembly
	Burn Grate—Super Grate
	Burn Grate—Corn/Grain Combustion
	Fan w/gasket Convection Fan w/ gasket
KS5020-1040	Control Board— AcuTron 2
KS5020-1070	Door Assembly—black
KS5040-1090	Door Assembly—brass trim
	Door Handle
	Firebrick
KS5050-1130	Gasket—Door 5/8" Dia. X 60" long
KS5060-1160	Gasket—Window - Tape
KS5060-1150	Gasket—Ash Pan
KS5060-1200	Gasket—Exhaust
KS5060-1190	Glass—Neo-Ceramic
KS5070-1210	Igniter Assembly—Freestanding
KS5030-1060	Backing Plate—Multi-Fuel
	Backing Plate Drop Cover—Multi-Fuel
KS5100-1340	Switch—L120
KS5100-1320	Switch—F140
KS5100-1330	Switch—L250
KS5090-1290	Switch—Vacuum
KS5110-1350	Wire Harness—Main AcuTron