

Description	SKU
AIR CONTROL S-ASS'Y, SMALL PS	221-11090
ASH DUMP PLATE, SMALL PS/PI - 1997 AND UP	93005051
ASH DUMP SEAL PLATE, w/GUIDES - 1997 AND UP PEL PS/PI	93005052
ASHPAN ASS'Y, SML PS - NEW STYLE NO LATCH, NO PAWL	250-00217
ASHTRAP DOORS, 1997+ UP PS/PI - LARGE OR SMALL (2)	93005054
AUGER BUSHING PLATE, UPPER # - 1997 & UP PS/PI, LRG OR SML	93005093
AUGER BUSHING PLT, LOWER, SML - (GEARMOTOR) 1997 & UP SM PS/PI	93005094
AUGER DRIVE COLLAR, 1997 & UP - LARGE/SMALL PEL STOVE/INS	91002021
AUGER FLIGHT, SMALL PS/PI - - 1997 & UP, 1-1/4" PITCH	250-00537
AUGER MOTOR STOP, P9/P10 - - SMALL PS/PI 1997 & UP	93005095
AUGER MOTOR, ALL PS/PI# - EXCEPT 93-96 PELLETT INSERT	250-00526
AUGER SUB-ASS'Y, SMALL PS/PI - - 1997 & UP, 1-1/4" PITCH FLIGHT	93005092
BLOWER MNT BRKT, SML PELLETT - 97 PS/PI	93005016
BLOWER MOUNT GRMT/SPACER (4)# - 1997+ PEL/1995+ GAS	93005017
BLOWER, COMB, PI/PS - SMALL # - ALL 90-96, SML PI/PS 1997 & UP	250-00527
BLOWER, CONV, G3/G7-10/G14- # - 16/G18/G21-26/P9-10 - PHD KIT	250-00589
BLWR, CONVECTION, L-BRACKET - PIONEER/NEWPORT PS-PI	250-02402
BRUSH, BROOM STYLE # - REPLACES 93005530 & 93005531	250-00377
BURNPOT ASSY, '91 & UP SMALL - PS/PI - A.K.A. FIREPOT	99300170
CNTRL BRD PLUG, FOR OLD HRNS# - REPLACEMENT PART ONLY	250-00012
CNTRL BRD, ALL PEL 1997 & UP# - LARGE OR SMALL PS & PI	250-00011
DECOR. DOOR ASS'Y, GOLD - PIO - O/S BOLT-ON	224-13016
DOOR KEY, 1/4" HEX-KEY w/WOOD - HANDLE - 97 SMALL PI/PS	93005010
DOOR LATCH HOOK, 97 SML PI/PS - SERVICE PARTS	250-01028
DOOR SHELL, PIONEER - GOLD#	99300219
DOOR SHELL, PIONEER, BLK PNT - SLIP-ON STYLE	91002009
DOOR SHELL, PIONEER, PEWTER - SERVICE PART	250-01343
DOOR, LOPI PIO PS, w/OUT SHL - (HER BAY PS), COMPLETE w/GLASS	99300208
DOOR, ROLLER PLATE, SML PEL - 97 & UP PS/PI	93005012
DRAFT (FLOW) SWITCH # - ALL PS/PI/EXTREME	90-0791

DRAFT FLOW TUBING, ALL PS/PI - ALL PELLET FS & INSERTS	99300164
EXHAUST ADAPTER, SMALL PELLET - CAST ALUMINUM - FASCO 86664218	250-00428
FASTENER - BOLT - HHCS 1/4-20 x 1/2" - 5 PK	250-01383
FIREBACK, CST IRN, SML PS/PI# - FS & INS - BRICK PATTERN	250-00534
FUSE -5AMP CONTROL BOARD 5 PK - NEW DIAGNOSTIC BOARD 2006'	250-00081
FUSE HOLDER (IN-LINE)#	250-00310
FUSE, 5AMP, 5 - FOR INLINE # - FUSE ASSEMBLY - 93 & UP PEL	93-0695
FUSE, 6AMP, 5 - CONTROL BOARD - 1997 TO 2005' PS & PI 5 PK	93005019
GLASS CLIP SET P-BAY/N-BAY - FULL SET - SERVICE PARTS	250-02058
GLASS, FRONT, PELLET (SMALL) - 1997 & UP - 14.511" x 9.721"	93005080
GLASS, SIDE, PELLET (SMALL) - 1997 & UP - 3.554" x 9.721"	93005081
GRILL, BLACK FRONT - SMALL - '97 PELL FS/INS AND DVS FS	93005035
GSKT CEMENT (WHITE), 4oz. # - CHILDERS (DOOR)	99900409
GSKT, ASHPAN - 70" BLK TAPE - 1/2" x 1/8" TAPE WITH ADHESIVE	99900428
GSKT, CLEAN-OUT COVER -PELLET - EXCEPT ASTORIA, 3.723 x 2.000	250-00228
GSKT, CLEAN-OUT COVER -PELLET - EXCEPT ASTORIA, 3.723 x 2.000	250-00228
GSKT, COMB BLOWER (BODY), SML - 7.884" x 6.483" x 1/8"	250-00358
GSKT, COMB BLOWER(MOTOR), SML - 5.780" dia	99300135
GSKT, DOOR 7/8" x 100" BLK # - GSKT ONLY - VARIOUS WD/PEL/GAS	99900402
GSKT, DOOR 7/8" x 50' BLACK# - ROPE - MISC. GAS/WOOD/PELLET	91001300
GSKT, GLASS 5/8"x137" BLACK# - ALL PS & PI 1997 & UP	99900398
HANDLE, HOPPER LID - '97 & UP - SMALL PI, '97-00 SMALL PS	250-00378
HANDLE, HOPPER LID - LG PEL/ - 2000 SMALL PS	250-00380
HANDLE, PEL CNTRL BOARD 97# - UP LRG/SML - BLWR/HEAT OUTPUT	99300094
HINGE PLT WLD ASSY, SM PI/PS - 97 & UP, w/TWO BOLTS	93005082
HINGE SET, CONTROL PANEL - PS CONTROL BOARD PANEL	250-02430
HOOD ASSEMBLY O/A DUCT KIT - PELLET - SERVICE PART	250-00231
HOPPER LID LATCH - P10 # - 1997 & UP SMALL PELLET STOVE	93005028
HOPPER LID, PIONEER PS, 2001 - #214639 & UP	91002027
HOPPER LID, PIONEER PS, 97-00 - UP TO #214639	93005032
HOSE NIPPLE, BARBED (DRAFT)	250-00379

IGNITER, SM PS/PI - # - 1997 & UP	99300148
INSPECTION COVER (BACK PANEL) - NEWPORT/PIONEER PS	250-01290
INSPECTN COVERS, w/SCREWS - AUGER & UPPER BEARING	250-00982
KNOB PHNLIC, ASHPAN W/SCRW - (PELLET) & W2 AIR CONTROL	250-01008
LABEL, PELLET CONTROL BOARD # - SURFACE LABEL, CONTROL BOARD	250-02296
LID STOP ASS'Y, SML PEL STOVE	220-02047
LOG BRKT ASSY UNIVERSAL - USED ON ASSY 98900126	250-00007
MAGNET w/OUT SHEATH - w/ MOUNTING HW	250-00002
MANUAL, PELLET SERVICE - 1998 - TROUBLE SHOOTING	93508201
MANUAL, PIONEER (HER BAY) PS	250-00548
NAME TAG - PIONEER (SCRIPT) - w/ 1/2" OF ADHESIVE TAPE	250-00617
OUTSIDE AIR DUCT, PELLET # - 1.750" x 25.0'	99200135
PEDESTAL ASS'Y, PIONEER PS - BOLT-ON, 97 PEL FS	93005033
POWER CORD, PS/PI 1997 & UP # - 16 ga AWG w/RING & FML CNCTRS	250-00533
REFRACTORY SIDE CLIP, LEFT - 12 GA CR - 9.701 x 1.480	250-00468
REFRACTORY SIDE CLIP, RIGHT - 12 GA CR - 9.701 x 1.480	250-00469
RETROFIT, AUGER FLIGHT INSP. - COVER - ALL PS.PI 1998 & UP	91002012
RUBBER BUMPER, HOPPER LID - This is (1) each Bumper	250-00016
RUBBER BUMPER, MOTOR STOP# - 3/8" dia x .375" TALL - 2 EACH	250-00284
SCRAPER ROD ASSY 97' & UP - SMALL PS/PI ONLY	250-00026
SIDE PANEL, PIONEER PS LEFT - LIFT-OFF, 97 & UP	93005030
SIDE PANEL, PIONEER PS RIGHT - LIFT-OFF, 97 & UP	93005031
SNAP-DISC - 120deg CERAMIC# - NORMALLY OPEN - SYSTEM DISC.	250-00313
SNAP-DISC - 200deg NC # - NORMALLY CLOSED - HOPPER DISC.	250-00314
SNAP-DISC BRACKET (NEW STYLE) - 26 GA GLV - 3.264 x 2.000	250-00471
STOVE PACK, PIONEER PS 2005 - SERIAL #218243 & UP - #496	225-10496
STUD PLATE/HW ASSEMBLY - SM PI/PS	228-20004
WIRE HRNS, PEL, PS/PI 2005+# - REPLACES OLD HARNESS 100-00393	250-00017
WIRE/CABLE HANGER CLIP - SERVICE PART	250-01375