

622-1 Top
622-2 Upper Front
622-3 Fire Door Shield
622-4-L Left Front Column
622-4-R Right Front Column
622-5 Rear Baffle Plate
622-6-L Left Baffle Plate Frame
622-6-R Right Baffle Plate Frame
622-7-L Left Baffle Plate
622-7-R Right Baffle Plate
622-8 Center Front
622-9 Ash Door Shield
622-10-LF Left Front Leg
622-10-RF Right Front Leg
622-11-LR Left Rear Leg
622-11-RR Right Rear Leg
622-12-F Front Base Strip
622-12-R Rear Base Strip
622-13-L Left Side Base Strip
622-13-R Right Side Base Strip
622-14 Bottom
622-15-LF Left Front Baffle Plate Clamp
622-15-LR Left Rear Baffle Plate Clamp
622-15-RF Right Front Baffle Plate Clamp
622-15-RR Right Rear Baffle Plate Clamp
622-16 Ash Pit
622-17 Left Grate Hanger
622-18 Right Grate Hanger
622-19 Shaker Grate Bar
622-20 Short Grate Bar
622-21 Shaker Grate Bar Cog
622-22 Short Grate Bar Cog
622-23 Right Side Grate Panel
622-24 Fire Pot
622-25 Front Heater Dome
622-26 Rear Heater Dome
622-27 Smoke Curtain
622-28 Ventiduct
622-29-L Lower Rear Flue Collar
622-29-U Upper Rear Flue Collar
622-30 Outer Section Elbow
622-31 Inner Section Elbow
622-32 Elbow Check Draft
622-33 Top Grid
622-34 Left Side
622-35 Left Upper Brace
622-36 Lower Rear Back
622-37 Upper Rear Back
622-38 Left Baffle Plate Rod
622-39 Elbow Back Cover
622-40 Heater Hood
622-41 Water Pan

622-42 Right Baffle Plate Rod
622-43 Right Upper Brace
622-44 Right Side
622-45 Nickel Shaker Ring
622-46 Upper Front Screen
(Chrome or Enameled)
622-47 Name Plate
622-48 Inner Fire Door
622-49 Fire Door Hinge
622-50 Mica Frame
622-51 Mica Screen
622-52 Mica (8 to door)
622-53 Fire Door Handle
622-54 Fire Door Handle Bushing
622-55 Fire Door Handle Latch
622-56 Center Front Screen
(Chrome or Enameled)
622-57 Inner Ash Door
622-58 Ash Door Hinge
622-59 Ash Door Draft Control
622-60 Ash Door Handle
622-61 Ash Door Handle Bushing
622-62 Ash Door Handle Latch
622-63 Ash Pan
622-64 Shaker
622-65 Ash Guard

www.partsplus.com