

**TOP PARTS**

14-A Front Top Rail  
 14-B Back Top Rail  
 16-F Left Top Rail  
 22-3 Left Towel Rod Bracket (2)  
 22-4 Left Towel Rod Bracket (2)  
 22-30 Front Towel Rod  
 22-31 Side Towel Rod  
 14-G Pouch Feed Door  
 22-33 Pouch Feed Door Handle  
 567 8" Lid (4)  
 513 Short Center  
 506 Open Anchor Plate  
 508 Middle Anchor Plate  
 416-A French Anchor Plate  
 16-D Reservoir Top Frame  
 16-E Reservoir Lid (2)  
 K-59 Pipe Collar  
 No. 3 Damper Handle Knob  
 22-32 Damper Rod  
 543-X Damper Frame  
 544-X Sliding Damper  
 181-R Oven Top Plate (2)  
 16-C Arch Toe  
 16-B Oven Arch

**LEFT END PARTS**

418-I Pouch Feed  
 420-K Draft Frame  
 421-L Draft Drop Door  
 422-M Draft Slide (2)

**SHELF PARTS**

22-1 Right Shelf Bracket  
 22-2 Left Shelf Bracket

**FIRE BOX PARTS**

181-U Pouch Feed Lining  
 14-O Rear Open End Lining  
 WBJ Wood Fire Box Extension  
 1167 Water-hole Cover (2)  
 604 Rear or Front Shut-off Lining (2)  
 564-HB Right Back Lining  
 565-AH Right Center Lining  
 564-HF Right Front Lining  
 22-8 Front Open End Lining  
 22-12 Front Fire Door Frame  
 14-L Front Fire Door  
 22-28 Right Side Asbestos Lining  
 525 Grate Rest  
 526 Grate Slide  
 527-R Right Grate Bar  
 527-L Left Grate Bar

529-R Right Grate Cog  
 529-L Left Grate Cog  
 528 Rear or Front Grate Housing (2)  
 22-27 Shaker-Lifter

**FRONT PARTS**

22-5 Rear Leg (2)  
 22-6 Front Leg (2)  
 22-7 Oven Door  
 22-9 Soot Clean-out  
 22-16 Thermometer  
 22-17 Oven Door Handle  
 22-18 Oven Door Catch  
 22-19 Left Oven Door Brace  
 22-20 Right Oven Door Brace  
 22-21 Oven Door Spring Rod  
 22-22 Oven Door Spring  
 22-23 Fire-Ash or Reservoir Door Hinge (4)  
 22-24 Fire-Ash or Reservoir Door Rod (2)  
 22-25 Fire-Ash, Reservoir or Utility Door Handle (3)  
 22-26 Fire-Ash or Reservoir Door Catch (2)  
 22-29 Steel Range Front  
 381-Q Right End "T" Iron Brace