

- 1 Main Top.
- 2 Round Cover.
- 3 Short Center.
- 4 Long Center.
- 6 Expansion Piece.
- 7 Feed Door.
- 8 Grate.
- 9 Front Door.
- 10 Hearth Plate.
- 11 Hearth Plate Damper.
- 12 Hearth Bottom.
- 13 Lower Front.
- 14 Flue Stop.
- 15 Upper Front.
- 16 Fire Back.
- 17 Oven Slide.
- 18 Front Oven Plate.
- 19 Back Oven Plate.
- 20 Top Oven Plate.
- 21 Bottom Oven Plate.
- 22 Left Bottom Flue Strip.
- 23 Right Bottom Flue Strip.
- 24 Left Back Flue Strip.
- 25 Right Back Flue Strip.
- 26 Roll Damper.
- 27 Top Shelf.
- 28 Main Bottom.
- 29 Feet.
- 30 Flue Covers.
- 31 Right Jamb.