

Part Number	Description
Burner Assemblies	
AA-12-00002	Gas valve assembly NG - manual (1994)
AA-12-00003	Gas valve assembly LP - manual (1994)
AA-12-00004	Gas valve assembly NG - thermostat (1994)
AA-12-00005	Gas valve assembly LP - thermostat (1994)
05-02-00229	Main gas valve NG - manual (1994) - see remarks
05-02-00232	Main gas valve LP - manual (1994) - see remarks
05-02-00234	Main gas valve NG - modulating thermostat (1994) - see remarks
05-02-00235	Main gas valve LP - modulating thermostat (1994) - see remarks
05-02-00231	Gas Valve Plug (must order 2 for above valves)
05-02-00230	NG Regulator for above valve
05-02-00233	LP Regulator for above valve
05-07-00063	Thermocouple
05-01-00151	Interrupter
05-04-00018	Pilot - Nat. gas
05-04-00019	Pilot - L.P. gas
65-14-00035	Main orifice NG #35 (1994)
65-14-00051	Main orifice LP #51 (1994)
HA-15-00089	Pilot gas line
HA-15-00090	Main burner gas line
HA-16-00031	Burner Tube SG-3
Blowers	
AA-12-00006	Variable speed automatic blower kit (1994)
10-10-00132	Three - way fan switch (1994)
15-02-00043	Blower with motor (1994)
05-01-00157	Thermo disc
05-01-00191	Magnetic Thermo-disc bracket assembly
Logs	
35-01-00170	Coal bed and log set (1994)
35-01-00177	Rear log (1994)
35-01-00176	Arched front log with branch and ember base (1994)
35-01-00239	Glowing Inswool
Miscellaneous Items	
65-06-00302	Neo-Ceram glass
HA-15-00026	Door gasket
HA-15-00028	Window gasket
65-06-01049	Black Touch up paint
65-06-00149	Piezo igniter
65-06-00311	Piezo igniter cable (24")
05-01-00153	Flue switch