

KEY NO.	PART NO.	DESCRIPTION			QTY.
			SL30PT	SL30NT	
1	104026-01	Stove Log	•	•	1
2	098249-01	Nut, M5	•	•	2
3	**	Painted Base Assembly	•	•	1
4	104454-01	Bracket, Regulator	•	•	1
5	098867-10	Gas Regulator	•	•	1
	098867-14	Gas Regulator	•	•	1
6	104425-01	Inlet Tube	•	•	1
7	104422-03	Outlet Burner Tube	•	•	1
	111331-06	Outlet Burner Tube	•	•	1
8	099056-19	Burner Orifice Injector	•	•	1
	099056-26	Burner Orifice Injector	•	•	1
9	111124-01	Burner Retainer Spring	•	•	1
10	102980-01	Burner	•	•	1
11	101329-22	Control Valve	•	•	1
	101329-21	Control Valve	•	•	1
12	104472-01	Bracket	•	•	1
13	099211-01	Screw	•	•	2
14	102445-01	Piezo Ignitor	•	•	1
15	099387-13	Pilot Tube	•	•	1
16	098271-10	Ignitor Cable	•	•	1
17	104286-01	ODS Pilot	•	•	1
	104285-01	ODS Pilot	•	•	1
18	M11084-38	Screw, Hex Head (#8-18 x .38)	•	•	7
PARTS AVAILABLE — NOT SHOWN					
	100563-01	Warning Plate	•	•	1
	101054-01	Lighting Instructions Plate	•	•	1
	100565-01	Warning Plate Fastener	•	•	1
	101137-04	Hardware Kit	•	•	1

** Not a field replaceable part.