

KEY NO.	PART NO.	DESCRIPTION			QTY.
			SVYD18PRA	SVYD18NRA	
1	104026-01	Stove Log	•	•	1
2	103778-01	ODS Pilot	•	•	1
	103779-01	ODS Pilot	•	•	1
3	098249-01	ODS Nut			2
4	104423-02	Burner Outlet Tube	•	•	1
	104423-01	Burner Outlet Tube	•	•	1
5	098264-02	Male Connector	•	•	1
6	111124-01	Burner Retainer Spring	•	•	1
7	099056-19	Burner Orifice Injector	•	•	1
	099056-26	Burner Orifice Injector	•	•	1
8	102980-01	Burner	•	•	1
9	099387-13	Pilot Tube	•	•	1
	099387-15	Pilot Tube	•	•	1
10	103781-02	Gas Control Valve	•	•	1
	103781-01	Gas Control Valve	•	•	1
11	103345-02	Lower Bracket	•	•	1
12	M11084-38	Screw, #8 x 0.38	•	•	7
13	**	Painted Base Assembly	•	•	1
14	098271-10	Ignitor Cable	•	•	1
15	102445-01	Piezo Ignitor	•	•	1
16	103587-02	Plate, Switch	•	•	1
17	098304-01	Screw	•	•	2
18	103784-04	Flame Adjustment Knob Extension	•	•	1
19	103784-03	Off-Pilot-On Knob Extension	•	•	1
20	M12461-26	Screw, Hex Slit Wsr 10-32 x 0.38	•	•	4
21	100609-01	Pilot Tube (Regulator to Pilot)	•	•	1
22	099918-02	Pilot Regulator	•	•	1
23	103284-02	Wiring Harness	•	•	1
24	099998-01	Switch	•	•	1
PARTS AVAILABLE — NOT SHOWN					
	100563-01	Warning Plate	•	•	1
	103877-01	Lighting Instructions Plate	•	•	1
	100565-01	Warning Plate Fastener	•	•	1
	101137-04	Hardware Kit	•	•	1

**Not a field replaceable part.