

PART #	DESCRIPTION	NUMBER REQUIRED	PART #	DESCRIPTION	NUMBER REQUIRED
1420	Hearthmount Combustor Package	1 set	14216	Railing Set Complete	1
14115	Combustion Air Control	1	14220	Blower Assembly c/w Knob	1
14125	Cast Grate	2	14221	Heat Sensor	1
14135	Flange Plate	1	14222	Switch Knob	1
14150	Flue Adaptor	1	14223	Blower Switch	1
14155	Control Tool	1	14225	Ash Catch	1
14160	Ash Pan	1	14230	Left Hand Screen	1
14170	Ash Pan Cover	1	14235	Right Hand Screen	1
14180	Combustor Cover Plate	1	14240	Door Frame with Inner Lining & Gasket	1
14185	Logo	1	14244	5MM Etched Glass	1
14190	2 Hole Railing Knob	4	14245	5MM Plain Glass	1
14195	1 Hole Railing Knob	4	14246	Hinge Pin c/w 1 Washer and Nut	2
14200	Knob no Hole	1	14248	Steel Handle c/w Nut	1
14201	Knob with Screw	1	14249	Spring Handle	1
14205	12 13/16" Rod	2	14250	Door Latch	1
14210	5" Rod	2	14251	Glass Retainer	5
14215	4 9/16" Rod	2			

Kodmanskpartsplus.com