

Remove the Skamol parts from the stove in the order indicated on drawing A.  
Install the new Skamol parts in the combustion chamber in the order indicated on drawing B.

