

No.

- 1 Closet Left Back Guard Corner—Nickel.
- 2 Closet Right Back Guard Corner—Nickel.
- 3 Closet Corner, Left—Nickel.
- 4 Closet Corner, Right—Nickel.
- 5 Closet Handle—Nickel.
- 6 Closet Top Front Nickel Band.
- 7 Closet Bottom Front Nickel Band.
- 8 Closet Left Hinge (not shown).
- 42 Closet Right Hinge.
- 9 Closet Left Upright Bracket—Nickel.
- 10 Closet Right Upright Bracket—Nickel.
- 11 Closet Tea Pot Shelf—Nickel.
- 12 Closet Tea Pot Shelf Bracket—Nickel.
- 13 Closet Pipe Check Damper Frame only—Nickel.
- 14 Closet Pipe Check Damper.
- 15 Closet Pipe complete with Damper.
- 16 Roll Damper Handle.
- 17 Roll Damper.
- 18 Back Top.
- 19 Left Top.
- 20 Front Top.
- 21 Right Top.
- 22 Anchor Plate Strip for Top.
- 23 Open Anchor Plate.
- 24 Closed Anchor Plate.
- 25 Short Center.
- 26 Round Cover.
- 27 Center Section Graduated Cover.
- 28 Middle Section Graduated Cover.
- 29 Outer Section Graduated Cover.
- 30 Towel Rod Bracket—Nickel.
- 31 Towel Rod—Nickel.
- 32 Right End (or Top) Shelf.
- 33 Right End Cast Asbestos Strip.
- 34 Front Cast Asbestos Strip.
- 35 Rear Cast Asbestos Strip.
- 36 Cast Top Oven Plate Liners.
- 37 Top Oven Brace (or Center Support).
- 38 Roll Damper Frame.
- 39 Reservoir Main Top.
- 40 Inside Reservoir Top—Japanned.
- 41 Reservoir Cover—Japanned.
- 42 Closet Right Hinge.
- 43 Pouch Door.
- 44 Pouch Door Register.
- 45 Pouch Door Frame.
- 46 Upper Front.
- 47 Grate Hole Cover.
- 48 Malleable Latches.
- 50 Front Slide Damper.
- 51 Front Slide Damper Knob.
- 52 Lower Front.
- 53 Left Oven Door Hinge.
- 54 Right Oven Door Hinge.
- 55 Hook for Oven Door Spring.
- 56 Oven Door Spring.

No.

- 57 Oven Door Spring Cover.
- 58 Reservoir Damper.
- 59 Reservoir Damper Frame.
- 60 Reservoir Damper Handle.
- 61 Reservoir Main Front.
- 62 Reservoir Panel—Nickel.
- 63 Oven Slide.
- 64 Bottom Flue Strip.
- 65 Clean Out Door Frame.
- 66 Clean Out Door—Nickel.
- 67 Clean Out Door Turn Key—Nickel.
- 68 Front Section Cast Base.
- 69 End Section Cast Base—Right or Left?
- 70 Back Section Cast Base—(Not shown).
- 71 Left End Damper Frame.
- 72 Left End Slide Damper.
- 73 Left End Slide Damper Knob.
- 74 Water Back Button.
- 75 Ash Door.
- 76 Hinge Pin.
- 77 Ash Pan.
- 78 Ash Pan Handle.
- 79 Oven Door Catch.
- 80 Oven Door Latch—Nickel.
- 81 Oven Door Latch Guide—Nickel.
- 82 Oven Door Handle—Nickel.
- 83 Oven Door Frame—Nickel.
- 84 Oven Door Panel—Nickel.
- 85 Oven Door Steel Plate.
- 86 "L" Water Back.
- 87 Water Front.
- 88 Front Drop Fire Door.
- 89 Front Drop Fire Door Panel—Nickel.
- 90 Front Drop Fire Door Panel Knob—Nickel.
- 92 Reservoir Cast Bottom Plate (not shown).
- 93 Reservoir Right End (not shown).
- 94 Reservoir Back (not shown).
- 95 Rear Section Fire Back.
- 96 Middle Section Fire Back.
- 97 Front Section Fire Back.
- 98 Rear Key Lining.
- 99 Front Key Lining.
- 100 Rear Key Lining Frame.
- 101 Front Key Lining Frame.
- 102 Sectional Fire Back Hanger Cast Strip.
- 103 Long End Grate.
- 104 Long Section Duplex Grate.
- 105 Short Section Duplex Grate.
- 106 Long Section Duplex Grate Cog.
- 107 Short Section Duplex Grate Cog.
- 108 Duplex Grate Rest
- 109 Grate Rest Bed Plate.
- 110 Cast Liner for Front Oven Plate.
- 111 High Closet Steel Door (less handle and hinges).