

#612

SCH#	DESCRIPTION	COLOR	PART #
007	Hinge		4074680
008	Screw M8 x 20 w/o head		0294045
009	Ash removal flap		4200494
010	Hinge		4074680
010B	Left cast iron panel		4200489
011	Front cast iron panel		4225416
012	Left and right ash screen		4077055
013	Flame screen		4200780
014	Bottom grate - left		4200235
016	Left furnace paddle		4200738
017A	Front half raise of hopper		4201503
020	Front half firebasket		4200733
021	Cooking plate complete		4077612
022	Loading valve		4275331
023	Gasketing - load valve		4771606
024	Loading valve protection plate-NUL		4200793
	Loading valve protection plate-ul		4073425
025	Hinge for loading valve		4275333
026	Heat exchanger kit w/c.i chimney		4079238
028	Back plate		4225676
029	Half hopper		4200737
030	Recuperator fixture		4404001
031	Gasketing		6006034
032	Right furnace paddle		4200739
033	Back half fire basket		4200732
034	Butterfly		4225374
035	Butterfly screw		4703194
036	Cleanout plate		4072702
037	Bottom grate - right		4225447
038	Gasketing - cleanout plate		6006034
039	Rivet - thermostat knob		4702469
040	Thermostat knob		4075344
041	Slider of shaker grate		4404324
042	Stove tool		4225331
043	Poker		4704603
045	Back support of cradle		4200786
046	Thermostat protection screen		4404878
048	Split pin		0231480
049	Buselure of thermostat		4701527
050	Mayer thermostat and valve		4009057
051	Flexible cable		4701773
052	Axis for thermostat knob		4701533
053	Basket support extension		4200541
054	Box for sliding grate		4225253
055	Right cast iron panel		4200490
056	Emptying grate		4225673
057	Cradle for back railing		4225448
058	Bottom		4225556
059	Ashtray		4009089
060	Interior support of side panel		4503273
061	Right foot		4077684
064	Hinge of pyrex door		4225237
066	Split pin		0231750
067	Ashtray door		4225468
068	Ashtray door handle		4225240
069	Support for ashtray		4225239
070	Support ring for ashtray door handle		4702679
071	Axis for ashtray door handle		4702678
074	Left foot		4077684
075	Ash removal flap hinge		4410696
076	Gasketing - ashtray door		200038
080B	Gasketing - pyrex door		200038
081	Pyrex door		4225671
082	Pin for pyrex door		0321700
083	Gasketing - pyrex glass		4771610
084	Gasketing - pyrex glass		4771610
085	Pyrex glass		4774757
087	Magnetic lock		4077688
088	Fixing plate for magnetic lock		4503326
090	Pyrex door handle complete		4072818
093	Horizontal pyrex tightener		4405456
094	Vertical pyrex tightener		4404331
095	Chrome frame for pyrex door		4766027
096	Fastening of upper front panel		4702474
097	Fastening of side panel		4702798
098	Tubular clips		4702799
100	Pyrex glass protection screen		4766055
101	Chimney adaptor		4503392
102	Back ash screen		4503283
103	Poker support		4078359