

#713

SCH#	DESCRIPTION	PART #
001	Pyrex door handle - complete	4073345
002	Axis for pyrex door handle	4701783
009	Left & right lengthener for head	4503307
012	Hinge	4074680
017	Left interior support - side panel	4503240
017B	Cover frame knob	4801174
019	Screw TC M8 x 20 without head	0294045
020	Front case iron panel	4225233
021	Left cast iron panel	4200489
022	Left and right ash screen	4077055
023	Bottom grate - left	4200486
024	Back half fire basket	4200492
025	Left furnace paddle	4200536
026	Half hopper	4200488
027	Top of hopper	4225551
029	Loading valve	4225550
030	Loading valve gasket 2'	4771606
031	Loading valve protection plate	4073870
031A	Loading valve protection plate	4201209
032	Pin 6 x 36	0231700
033A	Heat exchanger kit & cast iron chimney	4079154
035	Right cast iron panel	4200490
036	Gasketing 18"	6006034
037	Recuperator fixture	4404001
038	Right furnace paddle	4200537
039	Back plate	4225677
040	Butterfly	4225374
041	Butterfly screw	4703194
042	Cleanout plate	4072702
043	Cleanout plate gasketing 16"	6006034
044	Slider of shaker grate	4404324
045	Rivet	4702469
046	Thermostat knob	4075344
047	Support axis for gasket	4502253
048	Stove tool	4225331
049	Poker	4704603
050	Standard hook	0628202
052	Thermostat protection screen	4404878
052B	Thermostat protection crossing	4073433
053	Split pin	0231480
054	Buselure of thermostat	4701527
055	Mayer thermostat and valve	4009057
056	Valve for mayer thermostat	4076039
057	Flexible cable	4701759
058	Axis for handle (thermostat knob)	4701533
060	Basket support extension	4200541
062	Box for sliding grate	4225253
063	Front half fire basket	4200648
064	Bottom	4225552
065	Emptying grate	4225601
066	Right int. support side panel	4503241
067	Cradle for bottom grate	4200487
068	Foot	4077056
069	Bottom grate-right	4200636
070	Ashtray	4008192
072	Hinge of pyrex door	4225569
073	Central ash screen	4405082
074	Hinge of ashtray door	4225238
075	Split pin	0231750
077	Axis for ashtray door handle	4702678
078	Support for ashtray	4225239
079	Ashtray door handle	4225240
080	Support ring ashtray door handle	4702679
082	Ashtray door	4225467
083	Ash removal flap	4200494
084	Ash removal flap hinge	4410696
085	Ashtray door gasket 3/8" 4'2"	200038
086	Hinge	4074680
091	Pyrex door gasket 3/8" 5'	200038
092	Pyrex door	4225568
093	Split pin	0231700
094	Pyrex glass gasket	4771610
095	Pyrex glass gasket	4771610
097	Individual piece pyrex glass	4774757
098	Vertical pyrex tightener	4404331
099	Pin for speed nut	4704605
101	Horizontal pyrex tightner	4405371
106	Back ash screen	4503283
107	Chimney adaptor	4503392
108	Poker support	4078359
110	Interior floor protection	4073473