

Accessories:	Description	Part# LIL
1.	Handle for pyrex door - complete	4073345
2.	Axle for pyrex door handle	4701763
3.	Front border for hood	4078212
4.	Fixing plate for magnetic lock	4503877
5.	Left ornament (man)	4250891
6.	Left side panel	4070828
7.	Left back support of hood	4502776
8.	Left and right lengths for head	4504024
9.	Hood	4070831
10.	Hinge	4074860
11.	Punched plate for cover	4503990
12.	Cover	4250845
13.	Fixation square for back sleeper of hood	4079248
14.	Rest loader	4504023
15.	Reinforcement of top cover support	4504017
16.	Door frame knob	4703983
17.	Left support of side panel	4503240
18.	Right back support of hood	4502777
19.	Screw without head	0294045
20.	Inside front cast iron	4225813
21.	Left side panel	4201388
22.	Left and right ash screens	4077055
23.	Left bottom grate	4201388
24.	Back half of fire basket	4200492
25.	Lower front part of reservoir	4201393
26.	Upper front part of reservoir	4201392
27.	Head	4225859
28.	Loading valve	4225550
29.	Load Valve gasket	4772105
30.	Loading valve protection plate	4201209
31.	Pin	0231700
32.	Recuperator	4079148
33.	Back part of reservoir	4073344
34.	Chimney	4225860
35.	Lateral clean out gasket	4772116
36.	Butterfly	4225374
37.	Butterfly screw	4703184
38.	Lateral clean out plate	4225810
39.	Fixed support for stove back	4404451
40.	Leg fixing back part	4225868
41.	Right side panel	4201388
42.	Back plate	4225811
43.	Back ash screen	4503283
44.	Guide of air secondary pull handle	4225843
45.	Air secondary pull handle	4503814
46.	Clean out plate	4225576
47.	Clean out gasket	4772114
48.	Air secondary pull handle	4250593
49.	Rivet	4702489
50.	Thermostat knob	4075344
51.	Support axis for handle	4502253
52.	Stove tool	4225331
53.	Poker (short)	4704803
54.	Poker (long)	4078409
55.	Standard hook	0628202
56.	Thermostat protection screen	4404878
57.	Thermostat protection crossing	4503280

Schematic #	Description	Part No.
59.	Split pin	0231480
60.	Buselure of thermostat	4701527
61.	Mayer thermostat and valve	4009057
62.	Valve for Mayer thermostat	4078039
63.	Flexible cable	4704582
64.	Axis for handle	4701533
65.	Basket support extension	4201390
66.	Closing lid for right side	4503987
67.	Front half of fire basket	4200848
68.	Bottom	4225352
69.	Hook for front fixture	4407806
70.	Right support of side panel	4503241
71.	Cradle for back railing	4200487
72.	Right foot	4250878
73.	Right bottom grate	4201367
74.	Ashtray	4008192
75.	Sheet iron bottom grate	4503261
76.	Hinge of pyrex door	4225569
77.	Central ash screen	4405082
78.	Hinge of ashtray door	4225238
79.	Split pin	0831750
80.	Small wheel for ashtray door handle	4701787
81.	Axis for door knob ashtray	4702678
81B.	Skirt	4078155
82.	Support for ashtray	4225239
83.	Ashtray handle assembled	4225240
84.	Support ring ashtray door handle	4702678
86.	Ashtray door	4225867
87.	Ash flap	4200494
88.	Ashflap hinge	4410896
89.	Ash door gasket	4772114
90.	Hinge	4074680
91.	Side border for hood	4078211
92.	Left foot	4250877
93.	Right side panel	4503988
94.	Right ornament (woman)	4250682
95.	Pyrex door gasket	4772116
96.	Pyrex door	4225568
97.	Split pin	0231700
98.	Pyrex glass gasket	4772117
99.	Pyrex glass gasket	4772117
100.	Support lower panel of front	4503239
101.	Pyrex glass	4774757
102.	Vertical pyrex tightener	4404331
103.	Small clamp	4077861
104.	Shield	4250580
105.	Ornament for lower front	4504026
106.	Horizontal pyrex tightener	4405378
107.	Ornament frame for pyrex door	4250492
108.	Lower panel of front	4078214
109.	Pyrex glass protection	476606