

Symphony Wood 387.64

Reference Number	Part Number	Description
1	13237	Front Door Cast
1	13260	Front Door Beige
1	13277	Front Door Red
1	13286	Front Door Blue
1	13295	Front Door Black
1	13304	Front Door Dark Grey
1	13313	Front Door Light Grey
1	13322	Front Door Green
1	13332	Front Door Brown
2	13235	Combustion Chamber Front Cast
2	13261	Combustion Chamber Front Beige
2	13278	Combustion Chamber Front Red
2	13287	Combustion Chamber Front Blue
2	13296	Combustion Chamber Front Black
2	13305	Combustion Chamber Front Dark Grey
2	13314	Combustion Chamber Front Light Grey
2	13323	Combustion Chamber Front Green
2	13333	Combustion Chamber Front Brown
3	13241	Left Hand Side Panel Cast
3	13262	Left Hand Side Panel Beige
3	13279	Left Hand Side Panel Red
3	13288	Left Hand Side Panel Blue
3	13297	Left Hand Side Panel Black
3	13306	Left Hand Side Panel Dark Grey
3	13315	Left Hand Side Panel Light Grey
3	13324	Left Hand Side Panel Green
3	13334	Left Hand Side Panel Brown
4	13242	Right Hand Side Panel Cast
4	13263	Right Hand Side Panel Beige
4	13280	Right Hand Side Panel Red
4	13289	Right Hand Side Panel Blue
4	13298	Right Hand Side Panel Black
4	13307	Right Hand Side Panel Dark Grey
4	13316	Right Hand Side Panel Light Grey
4	13325	Right Hand Side Panel Green
4	13335	Right Hand Side Panel Brown
5	13233	Combustion Chamber Left Side Panel
6	13234	Combustion Chamber Right Side Panel
7	13239	Side Loading Door Cast
8	13236	Fire Box Top Cast
8	13264	Fire Box Top Beige
8	13281	Fire Box Top Red

Symphony Wood 387.64

Reference Number	Part Number	Description
8	13290	Fire Box Top Blue
8	13299	Fire Box Top Black
8	13308	Fire Box Top Dark Grey
8	13317	Fire Box Top Light Grey
8	13327	Fire Box Top Green
8	13336	Fire Box Top Brown
9	13231	Bottom Cast
9	13273	Bottom Beige
9	13282	Bottom Red
9	13291	Bottom Blue
9	13300	Bottom Black
9	13309	Bottom Dark Grey
9	13318	Bottom Light Grey
9	13328	Bottom Green
9	13337	Bottom Brown
10	13243	Front Ash Lip Cast
10	13274	Front Ash Lip Beige
10	13283	Front Ash Lip Red
10	13292	Front Ash Lip Blue
10	13301	Front Ash Lip Black
10	13310	Front Ash Lip Dark Grey
10	13319	Front Ash Lip Light Grey
10	13329	Front Ash Lip Green
10	13338	Front Ash Lip Brown
11	13232	Combustion Chamber Back Panel
12	13245	De Ash Grate
13	13244	Bottom Grate
14	13248	Front Glass Protection Grate
15	13253	Deflector
16	13249	Left Baffle
17	13250	Right Baffle
18	13477	Baffle Back Support
19	13251	Front Baffle
20	13252	Top Protector
21	13240	Flue Collar Coverplate Cast
21	13275	Flue Collar Coverplate Beige
21	13284	Flue Collar Coverplate Red
21	13293	Flue Collar Coverplate Blue
21	13302	Flue Collar Coverplate Black
21	13311	Flue Collar Coverplate Dark Grey
21	13320	Flue Collar Coverplate Light Grey
21	13330	Flue Collar Coverplate Green

Symphony Wood 387.64

Reference Number	Part Number	Description
21	13339	Flue Collar Coverplate Brown
22	13230	Foot Cast
22	13276	Foot Beige
22	13285	Foot Red
22	13294	Foot Blue
22	13303	Foot Black
22	13312	Foot Dark Grey
22	13321	Foot Light Grey
22	13331	Foot Green
22	13340	Foot Brown
23	13238	Pipe Cast
23	13424	Pipe Beige
23	13425	Pipe Red
23	13426	Pipe Blue
23	13427	Pipe Black
23	13428	Pipe Dark Grey
23	13429	Pipe Light Grey
23	13430	Pipe Green
23	13431	Pipe Brown
30	13254	Ash Pan
31	13256	Ground Protector
32	13255	Rear Heat Shield (Europe)
33	13257	Shaking Mechanism Stop Gap
34	6089	Fixing Piece Foot
35	13479	Glass Holder
36	13347	Stop Gap
38	13258	Extension for Rear Heat Shield
39	13259	Rear Heat Shield (USA)
40	13540	Fire Box Door Handle (Europe)
41	13541	Loading Door Latch (Europe)
42	13341	Tie Rod
43	13342	Special Nail
44	5713	Rapid Nut
45	13344	Pyrocerame Glass
46	13542	Glass Gasket
47	13609	Glass Holder Gasket
48	12433	Door Hinge Pin
49	12243	Loading Door Hinge Pin
50	4138	8 MM Asbestos Cerope
51	11329	12 MM Asbestos Cerope
52	13345	14 MM Asbestos Cerope
53	13543	Brass Knob Loading Door (USA)

Symphony Wood 387.64

Reference Number	Part Number	Description
54	13544	Brass Knob Front Door (USA)
63	5301	Plastic Door Handle (USA)
65	13778	5 x 20 Hex Screw
66	13779	5 x 30 Hex Screw
67	13780	Allen Wrench for Hex Screw
68	13781	Shouldered Screw 5 x 35
	5387	Grey Spray Paint
	16240	Touch Up Paint Beige
	13100	Touch Up Paint Red
	13101	Touch Up Paint Blue
	13102	Touch Up Paint Black
	13099	Touch Up Paint Dark Grey
	15164	Touch Up Paint Light Grey
	13103	Touch Up Paint Green
	13098	Touch Up Paint Brown

Woodmanspartsplus.com