

Part Number	Description
<b>Burner Assemblies</b>	
HA-26-00004	Valve assembly - NG (1996 - 1999)
HA-26-00005	Valve assembly - LP (1996 - 1999)
05-02-00238	Main gas valve - NG (1996 - 1999)
05-02-00239	Main gas valve - LP (1996 - 1999)
HA-26-00012	Burner tube weldment (1996 - 1999)
05-04-00022	Pilot Hood & Ignitor - (1996 - 1999) <b>SEE REMARKS</b>
65-03-00018	Pilot orifice - LP (1996 - 1999)
65-03-00021	Pilot orifice - NG (1996 - 1999)
65-14-00028	Main orifice - NG #28 (1996 - 1999)
65-14-00044	Main orifice - LP #44 (1996 - 1999)
05-02-00237	Hi/Low regulator - NG (1996 - 1999)
05-02-00236	Hi/Low regulator - LP (1996 - 1999)
05-07-00061	Thermopile
HA-25-00039	Main burner gas line
HA-25-00038	Pilot gas line
AA-11-00278	NG to LP conversion kit (1996 - 1999)
AA-11-00279	LP to NG conversion kit (1996 - 1999)
<b>Blowers</b>	
HA-26-00007	Blower assembly (1996 - 1999)
15-02-00047	Blower with motor (1996 - 1999) ( Squirrel cage 7' long x 2" diameter )
10-01-00046	Rheostat
05-01-00157	Thermodisc
<b>Logs</b>	
35-01-00214	Split log - 24" (1996 - 1999)
35-01-00187	Bag of Coals
35-01-00239	Glowing Inswool
<b>Miscellaneous Items</b>	
65-06-00400	Glass - front pane (1996 - 1999)
65-06-00401	Glass - side pane (1996 - 1999)
65-06-01049	Black Touch up paint
10-10-00104	On/Off switch
65-06-00149	Piezo igniter