

UVC36/43

		B41/B42 UVC36	D41 UVC43
Item/Model Number		Part Number	Part Number
1	LOG ASSEMBLY	55628	55752
1a.	LOG FRONT LEFT/RIGHT EMBER SET	B1	BF1
2a.	BURNER FRONT WITH TILES NAT.	55540	55567
2b.	BURNER FRONT WITH TILES PROP.	55541	55568
3a.	BURNER MAIN WITH TILES NAT.	55542	55569
3b.	BURNER MAIN WITH TILES PROP.	55543	55570
4.	CERAMIC TILE (SINGLE)	54330	54330
5a.	ORIFICE MAIN BURNER LP	50999	50701
5b.	ORIFICE MAIN BURNER NAT.	54527	55576
6a.	ORIFICE FRONT BURNER LP	54528	53552
6b.	ORIFICE FRONT BURNER NAT.	50701	54832
7.	FAN WITH BRACKET	52677	52677
8.	ELECTRICAL CORD	51865	51865
9.	FAN TEMPERATURE SENSOR	51704	51704
10.	SPEED CONTROL	51738	51738
11.	SPEED CONTROL KNOB	51882	51882
12.	GLASS WITH GASKET	55545	55573
13.	GASKET GLASS	55550	55571
14.	FRAME WINDOW	55544	55571
15.	TRIM FRAME WINDOW - AB/PB	OPTIONAL	OPTIONAL
16.	LOUVRE BOTTOM HINGES	52356	52356
17.	CERAMIC REFRACTORY KIT	OPTIONAL	OPTIONAL
18.	LOUVRE TOP ASSEMBLY	55546	55574
19.	LOUVRE BOTTOM ASSEMBLY	55547	55575
20.	WALL SWITCH - ON/OFF	51842	51842
21.	WALL SWITCH KIT	55532	55532
22.	PILOT TUBING	51873	51873
23.	CO CATALYST FILTER	55629	55629

Nova SIT 820 Valve

24a.	PILOT ASSEMBLY - RP	10001647	10001647
24b.	PILOT ASSEMBLY - RN	55464	55464
25.	IGNITOR PIEZZO	52464	52464
26.	CABLE IGNITOR (7522422) (NOT SHOWN)	51850	51850
27.	ELECTRODE IGNITOR*	ORDER PILOT ASSEMBLY	
28a.	VALVE - RP	55462	55462
28b.	VALVE - RN	55463	55463

Euro SIT 620 Valve

29a.	VALVE - TP	55649	55649
29b.	VALVE - TN	55651	55651
30a.	PILOT ASSEMBLY - TP	55467	55467
30b.	PILOT ASSEMBLY - TN	55466	55466

* Included in Pilot Assembly