

Radiance UVS27 Vent Free Stove Part List

UVS27 Vent Free Gas Heater - Freestanding Shell Models 2795, 2796, 2797, 2798

Ref.	Description	UVS27
1.	UVS27R Firebox Assembly NG	0002797
	UVS27R Firebox Assembly LP	0002798
	UVS27M Firebox Assembly NG	0002795
	UVS27M Firebox Assembly LP	0002796
2.	Rear Shroud Assembly, UVS27	20000894
3.	End, Left - FS-VF25J/SDV30/SNV	Refer to Enamel Parts Chart Page 49
4.	End, Right - FS-VF25J/SDV30/SNV30	Refer to Enamel Parts Chart Page 49
5.	Top, UV30	Refer to Enamel Parts Chart Page 49
6.	VC Front, FS	Refer to Enamel Parts Chart Page 49
7.	Hinge, Control Door - FS/HM	1601670
8.	Door, Control - FS/HM	1301087
9.	Heatshield, Side - DH25	1409065
10.	Damper - ENC/INT II	1601488
11.	Pan Hd PH 1/4-20 x 3/8" - Blk	1200993
13.	Washer, FL 1/4- Pln 7/8 o.d.	1202470
14.	Washer, FL 1/4-Z .3131 x .7420 .06+	1202474
16.	Wingscrew, 1/2-20 x 1/2 Pln	1201621
17.	Ring, Snap	1201987
18.	Leveling Bolt, Hex Hd 1/4-20 x 1/2 Z	1201745
19.	Screen, UVS27	20005009
20.	Grille, UV30	30000393
21.	Mesh, Grille 0 UV30	30000508
22.	Wiring/Thermostat Assembly - RVF	1601913
23.	Switch, ON/OFF - R/WDV	1601597

Color	Top	Left End	Right End	Front
Classic	N/A	N/A	N/A	N/A
Red	N/A	N/A	N/A	N/A
Sand	N/A	N/A	N/A	N/A
Midnight	N/A	N/A	N/A	N/A
Green	N/A	N/A	N/A	N/A