

Radiance UVS27 Hearthmount Vent Free Stove Part List

## UVS27 Vent Free Gas Heater - Hearthmount Shell Models 2795, 2796, 2797, 2798

Ref.	Description	UVS27
1.	UVS27R Firebox Assembly / NG	0002797
	UVS27R Firebox Assembly / LP	0002798
	UVS27M Firebox Assembly / NG	0002795
	UVS27M Firebox Assembly / LP	0002796
2.	Rear Shroud Assembly, UVS27	20000894
3.	End III, Left - HM/PDV	Refer to Enamel Parts Chart Page 51
4.	End III, Right - HM/PDV	Refer to Enamel Parts Chart Page 51
5.	Top, UV30	Refer to Enamel Parts Chart Page 51
6.	WF Front, HM	Refer to Enamel Parts Chart Page 51
7.	Hinge, Control Door - FS/HM	1601670
8.	Door, Control - FS/HM	Refer to Enamel Parts Chart Page 51
9.	Heatshield, Side - DH25	1409065
10.	Tab, Damper - ENC/INT II	1601488
11.	Pan Hd PH 1/4-20 x 3/8" - Blk	1200993
12.	Washer, FL 1/4 - Pin 7/8 o.d.	1202470
13.	Washer, FL 1/4-Z. 313i x .742o .06+	1202474
16.	Wingscrew, 1/4-20 x 1/2 - Pin	1201621
17.	Ring, Snap	1201987
18.	Leveling Bolt, Hex Hd 1/4-20 x 1-Z	1201745
19.	Screen, UVS27	20005009
20.	Grille, UV30	30000393
21.	Mesh, Grille - UV30	30000508
22.	Wiring/Thermostat Assembly - RVF	1601913
23.	Switch, ON/OFF - RWDV	1601597

Color	Top	Left End	Right End	Front	Control Door
Classic	N/A	N/A	N/A	1301129	1301087
Sand	N/A	N/A	N/A	1321129	1321087
Midnight	N/A	N/A	N/A	1341129	1341087