

VC100_C

REF #	Part #	Part Description	QTY
1	50000425	BASE ASSY	1
2	50000236	BRACE LEG END	2
24	50000260	SIDE SHELF PLATE	1
25	50000510	BRACE LEG FRONT 100	1
26A	50000414	REAR LID ASSY - CHARCOAL	1
26B	50000446	REAR LID ASSY - GREEN	1
27	50000007	LOGO	1
28A	50000419	FRONT LID ASSY - CHARCOAL	1
28B	50000449	FRONT LID ASSY - GREEN	1
29	50000096	PANEL BOTTOM - FOR LP MODEL ONLY	1
30	50000095	PANEL BOTTOM PLAIN	2
31	50000360	WHEEL (SET OF 2)	1
32	50000361	GREASE CUP HOLDER & GREASE CUPS (2)	1
33	50000642	GRIP HANDLE SET	1
34	50001643	TEMPERATURE GAUGE	1
35A	50000282	PANEL BASE - GREEN	1
35B	50000129	PANEL BASE - CHARCOAL	1
36A	50000529	DOOR 100 - LEFT; CHARCOAL	1
36B	50000544	DOOR 100 - LEFT; GREEN	1

VC100_C

37	50000365	LID BUMPERS (SET OF 6)	1
38	50000248	REGULATOR ASSY	1
39	50000355	PIVOT PIN & BOLT SET Send with lid assembly.	1
40	50000298	PLATE ROTISSERIE COVER	1
41	50000261	WARMING RACK	1
42A	50000530	DOOR 100 - RIGHT; CHARCOAL	1
42B	50000545	DOOR 100 - RIGHT; GREEN	1
43	50000024	HEAT SHIELD CONSOLE	1
N/A	50000303	VALVE ASSY LP	1
N/A	50000923	VALVE ASSY NG	1
N/A	50000359	CASTER & CASTER INSERT SET (SET OF 2)	1
N/A	50000452	HARDWARE PACK	1
N/A	50000468	DECAL	1
N/A	50000444	MANUAL USE AND CARE	1
N/A	50000953	MANUAL ASSY 100	1
N/A	50000504	TOOL HOLDER	1
3	50000237	BRACE LEG REAR	1
4	50000738	SHELF FRONT	2
5	50000463	CONSOLE 100B	1
6	50000038	BURNER ASSY	2
N/A	50003393	BURNER REPAIR KIT	1
7A	50000918	VALVE ASSY NG	1

VC100_C

7B	50000472	VALVE ASSY LP	1
8	50000356	HEAT PLATES; SET OF 2	1
9	50000099	SHELF SIDE RIGHT	1
10A	50000442	END CAP SHELF - LEFT	1
10B	50000441	END CAP SHELF - RIGHT	1
11	50000431	ELECTRODE MAIN SHORT	1
12	50000523	ELECTRODE MAIN LONG	1
13	50000093	AXLE	1
14	50000357	SMOKER BOX ASSEMBLY (SET)	1
15	50000043	FLASH TUBE	1
16	VCCG1A	COOKING GRIDS (SET OF 3)	1
17	50002395	IGNITER KIT	1
18	50000076	CONTROL KNOB	2
19	50000097	SHELF SIDE LEFT	1
20	50000027	GREASE PAN	1
21	50000079	LEG, LEFT	2
22	50000084	LEG, RIGHT	2
23	50000150	SUPPORT SHELF ASSY	2