

VC200_C

REF #	Part #	Part Description	QTY
1	50000425	BASE ASSY	1
2	50000236	BRACE LEG END	2
24	50000076	CONTROL KNOB	4
25A	50000456	TUBE & ORIFICE ASSEMBLY ROTISS - NG	1
25B	50000455	TUBE & ORIFICE ASSEMBLY ROTISS - LP	1
26	50000097	SIDE SHELF - LEFT	1
27A	50000414	REAR LID ASSY - BLACK. Also send p/n 5-0355.	1
27B	50000446	REAR LID ASSY - GREEN. Also send p/n 5-0355.	1
28A	50000419	FRONT LID ASSY - BLACK	1
28B	50000449	FRONT LID ASSY - GREEN	1
29	50000096	PANEL BOTTOM - FOR LP MODEL ONLY	1
30	50000095	PANEL BOTTOM PLAIN	2
31	50000360	WHEEL (SET OF 2)	1
32	50000361	GREASE CUP HOLDER & GREASE CUPS (2)	1
33	50000642	GRIP HANDLE SET	1
34	50001643	TEMPERATURE GAUGE	1
35A	50000129	PANEL BASE L - CHARCOAL	1
35B	50000282	PANEL BASE L - GREEN	1
36	50000369	REAR LOWER PANEL (BLACK) SET	2

VC200_C

37A	50000363	DOOR (FRONT) CHARCOAL	1
37B	50000366	DOOR (FRONT) GREEN	1
38	50000365	LID BUMPERS (SET OF 6)	1
39	50000248	REGULATOR ASSY	1
40	50000355	PIVOT PIN & BOLT SET Send with lid assembly.	1
41	50000746	ROTISSERIE HOUSING/SCREEN ASSY.	1
43	50000261	WARMING RACK	1
44A	50000454	TUBE and ORIFICE ASSEMBLY OVEN - NG	1
44B	50000453	TUBE and ORIFICE ASSEMBLY OVEN - LP	1
45	50000433	OVEN BURNER ASSY	1
N/A	50001011	IGNITOR - PUSH BUTTON	1
N/A	50000747	ROTISSERIE HOUSING / SCREEN ASSY.	1
N/A	50000399	ROTISSERIE SPIT ROD SUPPORT	1
N/A	50000286	ROTISSERIE SPIT ROD	1
N/A	50000287	ROTISSERIE WORK KIT	1
N/A	50000541	ROTISSERIE MOTOR BRACKET	1
N/A	50000151	ROTISSERIE BRACKET GUIDE	1
N/A	50000443	CONSOLE DECAL	1
N/A	50000504	TOOL HOLDER	1
N/A	VCRK1A	ROTISSERIE KIT	1
N/A	VC303-3666	BBQ COVER - SALE ITEM	1
3	50000237	BRACE LEG REAR	1

VC200_C

4	50000738	SHELF FRONT	2
5	50000429	CONSOLE 200 B	1
6	50000038	BURNER ASSY	2
N/A	50003393	BURNER REPAIR KIT	1
7A	50000919	VALVE ASSY NG	1
7B	50000470	VALVE ASSY LP	1
8	50000356	HEAT PLATES (SET OF 2)	1
9	50000099	SIDE SHELF - RIGHT	1
10	50000441	END CAP SHELF - RIGHT	1
11	50000442	END CAP SHELF - LEFT	1
12	50000431	ELECTRODE MAIN SHORT	1
13	50000523	ELECTRODE MAIN LONG	1
14	50000047	BURNER ROTISSERIE ASSEMBLY	1
15	50000466	ROTISSERIE ELECTRODE	1
16	50000093	AXLE	1
17	50000357	SMOKE BOX ASSY	1
18	50000043	FLASH TUBE	1
19	50000430	OVEN DEFLECTOR	1
20	VCCG1A	COOKING GRIDS; SET OF 3	1
21A	50000130	PANEL BASE R - CHARCOAL	1
21B	50000283	PANEL BASE R - GREEN	1
22	50000439	OVEN ELECTRODE	1

VC200_C

23	50000438	IGNITER KIT (Push button NOT included)	1
----	----------	--	---

Woodmanspartsplus