

VC500

REF #	Part #	Part Description	QTY
1	50001576	LOWER CABINET ASSEMBLY - S/S	1
2	50001524	CABINET END PANEL, LEFT - S/S	1
26	50000984	FRONT SHELF, RIGHT	1
27	50001556	SIDE SHELF RIGHT	1
28	50000120	S. BURNER COVER	1
29	50001551	TOWER MOUNT, PLATE	1
30	50001412	TOP SHELF - S/S	1
31	50001550	TOWEL COVER	1
32	50001552	TOWEL BAR	1
33	50001532	SIDE TRAY	1
35	50001594	WARMING RACK, ENAMEL	1
36	50000355	PIVOT PIN & BOLT SET Send with lid assembly.	1
37	50000880	FLASH TUBE	1
38	50001619	IGNITER MODULE - Push button not included.	1
3	50001525	CABINET END PANEL, RIGHT - S/S	1
4	50000789	CABINET UPPER PANEL	1
5	50001372	CABINET REAR PANEL, RIGHT - S/S	1
6	50001376	DOOR ASSEMBLY, LEFT - S/S	1
7	50001389	DOOR ASSEMBLY, RIGHT - S/S	1

VC500

62	50000882	HARDWARE BAG	1
63	50000126	GREASE CUP	1
64	50000313	DOOR HANDLE DELUXE	1
41	50000431	ELECTRODE, MAIN - SHORT	2
42	50000523	ELECTRODE, MAIN - LONG	3
43	50001011	IGNITER PUSH BUTTON	1
44	50000823	GREASE PAN ASSEMBLY	1
45A	50000803	VALVE ASSY - LP	1
45B	50000852	VALVE ASSY - NG	1
46A	50000804	REGULATOR LP	1
10	50001041	CABINET SLIDE, RIGHT	1
11	50001043	CABINET SLIDE, LEFT	1
12	50001174	BASE ASSY	1
13	50000857B	HEAT SHIELD	1
14	50001393	REAR LID ASSY Also send p/n 50000355.	1
15	50001585	ROTISSERIE HOUSING/SCREEN ASSEMBLY	1
16	50001388	FRONT LID ASSY - S/S Also send p/n 5-0355.	1
17	50001541	TANK TRAY ASSEMBLY	1
18	50001548	UPPER REAR PANEL - S/S	1
19	50001540	CONSOLE ASSY	1
20	50000779B	FRONT LIP	1
21	50000892	BURNER GASKET	5

VC500

8	50000797	DRAWER SUPPORT, RIGHT	1
9	50000798	DRAWER SUPPORT, LEFT	1
39	50001014	IGNITER WIRE, POSITIVE - 10	1
40	50001015	IGNITER WIRE, NEGATIVE - 10	1
46B	50000198	HOSE NG	1
47	50000177	LID BUMPERS	4
48	50000875	ROTISSERIE BURNER ASSEMBLY	1
49	50000981	ROTISSERIE ELECTRODE	1
50A	50000819	TUBE & ORIFICE ASSEMBLY, LP	1
50B	50000818	TUBE & ORIFICE ASSEMBLY, NG	1
51	50000962	ROTISSERIE SPIT ROD	1
52	50001327	BEZEL	6
53	50001767	COOKING GRIDS; (SET OF 4)	1
54	50000642	HANDLE GRIP SET	1
55	50001570	ROTISSERIE PART KIT	1
56	50001328	CONTROL KNOB	6
57	50001038	SMOKER BOX (WITHOUT LID)	1
58	50001039	SMOKER BOX LID	1
59	50000777	HEAT PLATE - S/S	5
60A	50001443	SIDE BURNER SUB-ASSY, LP	1
60B	50001296	SIDE BURNER SUB-ASSY, NG	1
61	50000809	CASTER (THREADED)	4

VC500

22	50003133	BURNER W. LONG ELECTRODE	3
N/A	50003100	BURNER W. SHORT ELECTRODE	2
23	50001549	DRAWER ASSEMBLY	1
24	50001418	SUPPORT SHELF, LEFT - BLACK	1
25	50001419	SUPPORT SHELF, RIGHT - BLACK	1

Woodmanspartsplus